




# BAITCASTING REEL

Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

## FUEGO CT 100H/100HS-100XS



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	H93-0401	SET PLT SCREW	58	320-5901	RETAINER
2	E16-7101	BRAKE DIAL SPRING	59	B41-1703	WASHER
3	J21-3703	BRAKE ADJ KNOB	60	G72-0001	WORM SHAFT BEARING
4	B33-9801	BRAKE DIAL RETAINER	61	J47-2101	LEVEL WIND
5	F63-7701	BRAKE DIAL WAHSER	62	121-4212	LINE GUIDE PAWL
6	H66-3401	BRAKE CLICK SPRING	63	373-1303	WASHER
7	H93-0130	LEFT SIDE PLATE	64	F40-2801	PAWL CAP
8	H91-5501	BRAKE DIAL RETAINER	65	J43-2701	LEVEL WIND GUARD
9	G93-9301	FRONT PLATE SCREW	66	J24-3602	WORM SHAFT
10	H93-0502	MAGNET HOLDER	67	G72-0001	WORM SHAFT BEARING
11	375-7406	SPACER	68	H91-0501	WORM GEAR
12	375-7411	SPACER	69	B33-9801	RETAINER
13	G18-5101	SPACER	70	G09-9801	WASHER
14	G51-1503	BALL BEARING	71	320-8002	RETAINER
15	F03-2201	BEARING RETAINER	72	B35-8607	BALL BEARING
16-24	Z02-2784	SPOOL ASSEMBLY	73	H92-8901	PLATE B
25	J33-7912	FRAME	74	E13-4509	SCREW
26	J24-4013	FRONT COVER	75	H91-2701	DRIVE SHAFT GEAR
27	H84-2803	SCREW	76	H91-1601	DRIVE SHAFT
28	J33-5001	CLUTCH LEVER	77	H92-9401	A/R RATCHET
29	H91-5601	CLUTCH LEVER PLT	78	J08-5101	DRIVE SHAFT WASHER
30	H91-5701	CLUTCH LEVER PLT	79	H91-3102	DRIVE GEAR
31	J43-7001	STABILIZER BAR	80	H45-2602	DRAG WASHER
32	H70-4101	RETAINER	81	H91-3201	KEY WASHER
33	H91-0601	COLLAR	82	J37-7801	GEAR SHAFT COLLAR
34	H92-8801	SPRING	83	G81-9801	ROLLER CLUTCH
35	J05-5201	PIN	84	B86-1704	BALL BEARING
36	B86-1704	BALL BEARING	85	B55-3801	WASHER
37	J24-2801	PLATE A	86	F02-8203	CLICK LEAF SPRING HOLDER
38	H29-4101	SCREW	87	F03-2401	BRAKE CLICK SPRING
39	J24-3201	CLUTCH CAM SPRING	88	150-8901	SPRING WASHER
40	J22-1401	CLUTCH TRIP LEVER	89	H92-9501	WASHER
41	J24-2601	CLUTCH CAM PLATE	90	H91-2001	NUT
42	H15-9201	WASHER	91	J01-1901	SPRING
43	352-2501	SCREW	92	H91-1901	STAR DRAG
44	H65-0101	CLUTCH CAM PLATE	93	F57-6601	HANDLE COLLAR
45	B03-2904	SCREW	94	J47-2201	HANDLE ASSEMBLY
46	H92-9001	YOKE	95	H72-3701	HANDLE NUT
47	H58-2001	PINION YOKE SPRING	96	J21-3502	HANDLE CAP
48	H91-3901	PINION GEAR	97	G04-0803	HANDLE CAP SCREW
49	H18-0501	BEARING RETAINER			
50	G43-1102	BALL BEARING			
51	J21-2155	RIGHT SIDE PLATE			
52	B05-5201	O'RING			
53	J21-3101	SPACER			
54	B17-5503	CAP RUBBER WASHER			
55	H21-3601	CAST CONTROL CAP			
56	G04-0820	SIDE PLATE SCREW			
57	G04-0828	SIDE PLATE SCREW			
58	320-5901	RETAINER			
59	B41-1703	WASHER			

FGCT100HS SPECIAL PARTS		
Key No.	Part No.	Part Name
48	J00-4201	PINION GEAR
51	J21-2156	RIGHT SIDE PLATE
79	J00-4002	DRIVE GEAR

FGCT100XS SPECIAL PARTS		
Key No.	Part No.	Part Name
48	J00-9801	PINION GEAR
51	J21-2157	RIGHT SIDE PLATE
79	J00-9902	DRIVE GEAR