




BAITCASTING REEL

LEXA-HD 400XSL-P

Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



KEY No.	PART No.	PART NAME	KEY No.	PART No.	PART NAME
1	460-5620	SET PLT SCREW	50	540-3980	WASHER
2	510-4450	SET PLT SPRING	51	380-0780	LINE GUIDE NUT
3	550-1700	BRAKE ADJ KNOB	52	270-0870	LEVEL WIND GUARD
4	510-5340	BRAKE CLICK SPRING	53	470-2430	WORM SHAFT
5	200-0530	BRAKE DIAL RET (A)	54	240-2300	WORM SHAFT GEAR
6	230-2595	R/S PLT	55	200-0530	GEAR RET
7	410-2720	BRAKE DIAL RET (B)	56	140-2030	BALL BEARING
8	230-2600	SET PLATE	57	200-0580	DRIVE GEAR SHAFT RET
9	460-3220	SCREW	58	410-2740	PLATE
10	240-2290	MAGNET HOLDER	59	460-5290	SCREW
11	430-1070	MAGNET HOLDER RET	60	540-6600	WASHER
12	540-8110	SPACER (A)	61	240-2260	DRIVE GEAR
13	140-1790	BALL BEARING	62	470-2441	DRIVE SHAFT
14	430-0440	BERING RET	63	460-5370	SCREW
15-18	700-9900	SPOOL ASSEMBLY	64	530-0860	A/R PAWL
19	410-2680	SPACER (B)	65	240-3030	A/R RATCHET
20	090-0290	CLUTCH LEVER	66	540-6670	SPACER (F)
21	410-2670	SPACER ©	67	250-1710	DRIVE GEAR
22	110-1180	FRAME	68	540-8090	DRAG WASHER
23	400-2570	PIN	69	540-8060	KEY WASHER
24	200-0580	WORM SHAFT RET	70	540-8100	WASHER
25	150-2260	BUSHING	71	540-7100	WASHER
26	170-1380	CLUTCH CAM	72	540-8070	TOP WASHER
27	410-2730	PLATE	73	150-2270	GEAR SHAFT COLLAR
28	510-5300	SPRING	74	140-2000	ROLLER CLUTCH
29	460-1290	SCREW	75	140-2040	BALL BEARING
30	400-3310	KICK LEVER PIN	76	540-6250	SPACING WASHER
31	330-2950	KICK LEVER	77	510-5370	PLATE
32	510-5320	KICK LEVER SPRING	78	460-7070	SCREW
33	410-2750	YOKE	79	540-6390	DRAG SPRING WASHER
34	510-6040	YOKE SPRING	80	540-9020	WASHER
35	200-0570	E-CLIP	81	700-7340	STAR DRAG
36	260-2211	PINION GEAR	82	510-3260	LEAF SPRING (B)
37	430-1061	BEARING RET	83	700-9950	HANDLE ASSEMBLY
38	150-2060	BUSHING	84	380-1441	HANDLE NUT
39	230-2585	L/S PLT	85	410-2500	HANDLE NUT PLT
40	460-7040	SCREW	86	460-4260	SCREW
41	460-5600	SCREW	87	400-3380	PILLAR
42	430-1000	O-RING	88	200-1160	E-CLIP
43	540-6460	SPACER	89	150-1050	BUSHING
44	540-5980	SPACER	90	510-5310	SPRING
45	380-1990	CAST CONTROL CAP	91	400-2720	PIN
46	460-5320	LONG SCREW	92	540-5380	WASHER
47	550-1725	FRONT PLT	93	210-2410	BUSHING
48	490-1100	LINE GUIDE	94	540-8120	WASHER
49	400-2540	LINE GUIDE PALW	95	540-7220	WASHER