




# BAITCASTING REEL

# STEEZSVTW1016SV-HL/SHL

Please order by parts number, not key number  
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	J33-4101	R/S PLT	65	B17-5503	WASHER
2	J28-6201	LEVER PLT SPRING	66	J27-9601	CAST CONTROL CAP
3	J28-6301	LEVER PLT PIN	67	G04-0822	SCREW
4	J33-4501	LEVER PLT (A)	68	G04-0826	SCREW
5	J28-6101	LEVER PLT (B)	69	320-5901	RETAINER
6	G94-0402	SCREW	70	B41-1702	WASHER
7	H15-9201	WASHER	71	G46-9001	BALL BEARING
8	J28-2602	BRAKE ADJ KNOB	72	J24-3301	LEVEL WIND
9	H66-3401	BRAKE CLICK SPRING	73	121-4212	LINE GUIDE PAWL
10	J33-4301	SET PLT	74	373-1300	WASHER
11	J29-6701	MAGNET HOLDER	75	F40-2801	PAWL CAP
12	H66-6001	SET PLT SCREW	76	J28-1601	WORM SHAFT PLATE
13	J31-5701	MAGNET HOLDER RET	77	J33-3801	WORM SHIELD
14	375-7404	BEARING WASHER	78	J24-3601	WORM SHAFT
15	375-7411	SPACER	79	G46-9001	BALL BEARING
16	G18-5101	WASHER	80	J28-1401	WORM SHAFT GEAR
17	G51-1506	BALL BEARING	81	B33-9801	RETAINER
18	F03-2201	BEARING RET	82	G09-9800	WASHER
19-29	Z02-2654	SPOOL ASSEMBLY	83	320-8002	RETAINER
30	J37-4501	FRAME	84	G46-6205	BALL BEARING
31	J28-1801	FRONT PLT	85	J28-1201	GEAR SHAFT PLT (A)
32	H53-1507	FRONT PLT SCREW	86	J28-1101	GEAR SHAFT PLT (B)
33	J28-0701	CLUTCH LEVER	87	E13-4511	SCREW
34	J28-0101	CLUTCH LEVER PLT (L)	88	J28-1001	WORM GEAR
35	J28-0001	CLUTCH LEVER PLT ®	89	J28-0902	DRIVE SHAFT
36	J28-1901	STABILIZER BAR	90	H66-0901	A/R RATCHET
37	H70-4101	STABILIZER BAR RET	91	374-6605	DRIVE GEAR WASHER
38	G43-1002	BALL BEARING	93	H03-3002	DRAG WASHER
39	H26-6601	COLLAR	94	F79-6301	KEY WASHER
40	J33-3601	KICK LEVER PLT (A)	95	J08-5201	EARED WASHER
41	H53-1506	SCREW	96	B36-0308	KEY WASHER (B)
42	H67-0501	CLUTCH CAM SPRING	97	G01-1401	COLLAR
43	J33-3701	KICK LEVER	98	G81-9801	ROLLER CLUTCH
44	J33-3501	CLUTCH CAM PLT	99	G43-1002	BALL BEARING
45	H92-8801	SPRING B	100	B55-3801	WASHER
46	J05-5201	PIN	101	F02-8203	CLICK LEAF SPRING HOLDER
47	J33-3001	CLUTCH CAM	102	F03-2401	BRAKE CLICK SPRING
48	H15-9201	WASHER	103	150-8901	SPRING WASHER
49	G28-1401	WASHER	104	H92-9501	WASHER
50	352-2509	SCREW	105	J14-1002	NUT
51	H65-9101	CLUTCH CAM PLT	106	J01-1901	SPRING
52	B03-2905	SCREW	107	J29-5401	STAR DRAG
53	H94-4401	YOKE	108	F57-6601	HANDLE COLLAR
54	J31-3901	YOKE SPRING	109	J29-6301	HANDLE
55+92	Z02-2724	PINION + DRIVE GEAR UNIT	110	J29-5501	HANDLE SCREW
56	H44-8402	RETAINER	111	J31-9201	HANDLE PLT
57	G53-8007	BALL BEARING	112	G83-5502	HANDLE SCREW
58	H15-9503	GEAR BUSHING			
59	J28-5901	PINION GEAR RING			
60	H44-0201	SPACER			
61	J33-2801	L/S PLT			
62	J27-9701	O'RING			
63	J27-9501	PINION SHAFT			
64	H16-1001	SPACER			

STEEZSVTW1016SV-SHL SPECIAL PARTS		
Key No.	Part No.	Part Name
55 + 92	Z02-2728	PINION + DRIVE GEAR UNIT
61	J33-4701	L/S PLT
111	J31-9202	HANDLE NUT PLT