




BAITCASTING REEL TATULA-HD200HL/200HSL

Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	H93-0401	SET PLATE SCREW	50	G04-0825	LEFT SIDE PLATE SCREW(B)
2	E16-7101	YOKE SPRING	51	320-5901	RETAINER(B)
3	H93-0207	BRAKE ADJ KNOB	52	B41-1700	WASHER(B)
4	B33-9801	BRAKE DIAL RETAINER(A)	53	G72-0001	WORM SHAFT SPACER (A)
5	F63-7701	BRAKE DIAL WASHER	54	H92-9101	T-LEVEL WIND
6	H66-3401	BRAKE CLICK SPRING	55	121-4212	LINE GUIDE PAWL
7	H94-4905	RIGHT SIDE PLATE	56	373-1300	WASHER(C)
8	H91-5501	BRAKE DIAL RETAINER(B)	57	F40-2801	LINE GUIDE NUT
9	G93-9301	FRONT PLATE SCREW	58	H94-4601	LEVEL WIND GUARD
10	H93-0501	MAGNET HOLDER	59	H91-1702	WORM SHAFT
11	375-7400	SPACER(A)	60	G72-0001	WORM SHAFT SPACER (B)
12	375-7411	SPACER(B)	61	H91-0501	WORM GEAR
13	G18-5101	SPACER(C)	62	B33-9801	RETAINER(C)
14	G51-1507	BALL BEARING(A)	63	G09-9800	WASHER(D)
15	F03-2201	BEARING RETAINER(A)	64	320-8002	RETAINER(D)
16-17	J09-1501	SPOOL ASSEMBLY	65	B35-8605	BALL BEARING(D)
18	H94-3908	FRAME	66	H92-8901	PLATE(B)
19	H93-0005	FRONT PLATE	67	E13-4509	SCREW(F)
20	H45-5402	SCREW(C)	68	H91-2701	DRIVE SHAFT GEAR
21	H91-2401	CLUTCH LEVER	69	H91-1602	DRIVE SHAFT
22	H91-5701	CLUTCH LEVER PLATE	70	H92-9401	A/R RATCHET
23	H91-5601	CLUTCH LEVER PLATE	71	J08-5101	DRIVE SHAFT WASHER (A)
24	H91-2101	STABILIZER BAR	72	J07-7002	DRIVE GEAR
25	H70-4101	RETAINER(A)	73	H45-2602	DRAG WASHER
26	H91-0601	COLLAR	74	H91-3201	KEY WASHER
27	H92-8801	SPRING(B)	75	G54-5001	GEAR SHAFT COLLAR
28	J05-5201	PIN	76	G81-9801	ROLLER CLUTCH
29	B86-1704	BALL BEARING(B)	77	B86-1704	BALL BEARING(E)
30	H94-4301	PLATE(A)	78	B55-3801	WASHER(E)
31	H29-4101	SCREW(D)	79	F02-8203	CLICK LEAF SPRING HOLDER
32	H47-3301	CLUTCH CAM SPRING	80	F03-2401	CLICK LEAF SPRING
33	H47-3401	CLUTCH TRIP LEVER	81	150-8901	DRAG SPRING WASHER
34	H94-4001	CLUTCH CAM PLATE	82	H92-9501	WASHER(F)
35	H15-9201	WASHER(A)	83	H91-2002	NUT
36	352-2501	A/R LEVER SCREW	84	J01-1901	SPRING(C)
37	H65-9101	CLUTCH CAM PLATE	85	H91-1901	STAR DRAG
38	B03-2904	CLUTCH CAM SCREW	86	F57-6601	HANDLE COLLAR
39	H94-4401	YOKE	87	J09-1201	HANDLE ASSEMBLY
40	J05-5301	YOKE SPRING	88	G79-3302	HANDLE NUT
41	J09-2001	PINION GEAR	89	040-3211	HANDLE PLATE
42	E21-9701	BEARING RETAINER(B)	90	353-8301	HANDLE SCREW
43	G43-1105	BALL BEARING(C)			
44	H94-3811	LEFT SIDE PLATE			
45	171-5201	"O"RING			
46	B17-5406	CAP RUBBER WASHER			
47	B17-5503	SPACER(G)			
48	J00-4704	CAST CONTROL CAP			
49	G04-0814	LEFT SIDE PLATE SCREW(A)			

TATULA -HD200HSL SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
3	H93-0210	BRAKE ADJ KNOB
41	J09-2101	PINION GEAR
44	H94-3812	LEFT SIDE PLATE
72	J07-6602	DRIVE GEAR