


**TEAM DAIWA – FUEGO**



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G03-6811	L/S PLT	53	320-1402	CLUTCH TRIP PLT RET
2	F57-7901	SET PLT SCREW	54	F79-4801	YOKE
3	E16-7101	SET PLT SPRING	55	G04-7201	YOKE SPRING
4	F57-7802	BRAKE ADJ KNOB	56	G62-0301	PINION GEAR
5	B33-9801	BRAKE ADJ KNOB RET	57	E21-9701	BEARING RET B
6	F63-7701	BRAKE ADJ KNOB WASHER	58	F05-5601	BALL BEARING C
7	F05-1701	BRAKE CLICK SPRING	59	G62-0201	R/S PLT
8	F61-3401	BRAKE DIAL RET	60	G04-0801	R/S PLT SCREW
9	G01-1902	LEFT SET PLT	61	171-5201	O RING
10	F71-7702	MAGNET HOLDER	62	G01-5501	PINION SHAFT
11	351-0906	LEFT SET PLT SCREW	63	B17-5401	SPOOL ADJ CAP METAL
12	B54-3201	MAGNET HOLDER RET	64	B17-5503	RUBBER WASHER
13	375-7404	SPACER A	65	F57-4408	CAST CONTROL CAP
14	375-7411	SPACER B	66	F64-7201	DRIVE SHAFT WASHER A
15	F57-4303	SPACER C	67	F05-5601	BALL BEARING D
16	G49-8601	BALL BEARING A	68	G40-6603	DRIVE SHAFT
17	E21-9701	BEARING RET A	69	G01-0001	DRIVE SHAFT RET
18-26,49	Z01-3713	SPOOL	70	E13-4503	DRIVE SHAFT RET SCREW A
27	G52-8112	FRAME	71	G02-1201	DRIVE SHAFT RET SCREW B
28	G00-9302	CLUTCH LEVER PLT A	72	G01-0201	DRIVE SHAFT RET SPRING
29	G00-9501	CLUTCH LEVER	73	F76-1701	A/R RATCHET
30	G00-9402	CLUTCH LEVER PLT B	74	E48-9502	DRIVE SHAFT WASHER B
31	320-5901	WORM SHAFT RET	75	G01-1201	DRIVE GEAR A
32	F65-5501	WORM SHAFT WASHER	76	G01-1301	DRIVE GEAR B
33	B71-5601	WORM SHAFT HOLDER A	77	F79-6101	EARED WASHER
34	F83-6502	WORM SHIELD	78	G42-8501	DRAG WASHER A
35	G41-0301	LINE GUIDE	79	F79-6301	KEY WASHER A
36	121-4212	LINE GUIDE PAWL	80	G45-5801	DRAG WASHER B
37	373-1300	LINE GUIDE WASHER	81	G14-1801	KEY WASHER B
38	F40-2801	PAWL CAP	82	G54-5001	GEAR SHAFT COLLAR
39	G41-7801	WORM SHAFT HOLDER B	83	F99-9803	ROLLER CLUTCH
40	B55-3801	ROLLER CLUTCH WASHER	84	F58-2501	BALL BEARING E
41	G56-5101	WORM SHAFT	85	B55-3801	BEARING WASHER
42	G01-1702	STABILIZER BAR	86	F02-8201	CLICK LEAF SPRING HOLDER
43	G01-1601	FRONT PLT	87	F03-2401	CLICK LEAF SPRING
44	F83-4701	BALL BEARING COLLAR	88	150-8901	SPRING WASHER
45	B86-1702	BALL BEARING B	89	373-7810	SPACING SLEEVE
46	F79-3501	CLUTCH CAM	90	F57-6506	STAR DRAG
47	G00-9601	YOKE PLT	91	F57-6601	FRICITION WASHER
48	G01-0101	YOKE PLT SPRING	92	G62-0401	HANDLE
50	G00-9701	CLUTCH CAM SCREW	93	B43-3601	HANDLE NUT
51	G00-9801	CLUTCH TRIP PLT	94	F57-7202	HANDLE NUT RET
52	371-6906	CLUTCH TRIP PLT WASHER	95	G26-2301	CLUTCH CAM PLT