


TRIFORCE-Z153A



Key No.	Parts No.	Parts Name
1	F82-1201	BRAKE ADJ KNOB
2	F05-1701	BRAKE CLICK SPRING
3	F82-1001	L/S PLT
4	B84-2102	BRAKE ADJ KNOB SCREW
5	374-9103	SPACER A
6	374-9105	SPACER B
7	E08-8003	BALL BEARING A
8	F41-2301	BEARING RET A
9	E23-9501	MAGNET HOLDER
10-12	F82-1401	SPOOL
13	F82-0601	FRAME
14	F40-2008	CLUTCH LEVER
15	F42-8801	CLUTCH TRIP PLT
16	F63-9901	CLUTCH TRIP PLT SPRING
17	F44-0201	CLUTCH TRIP PLT WASHER
18	F51-6501	LINE GUIDE PAWL
19	F40-2801	PAWL CAP
20	F51-0301	WORM SHAFT
21	F67-5101	WORM SHAFT GEAR
22	B86-1702	BALL BEARING B
23	F73-1201	CLUTCH CAM SPRING
24	F64-7001	CLUTCH CAM
25	F76-2601	FLIPPING CAST SELECTOR
26	F58-3401	PINION GEAR
27	E23-7701	YOKE
28	F86-4101	YOKE SPRING
29	E21-9701	BEARING RET B
30	F64-8301	BUSHING A
31	F82-0801	R/S PLT
32	F74-3001	PINION SHAFT

Key No.	Parts No.	Parts Name
33	B17-5401	SPOOL ADJ CAP METAL A
34	B17-5503	SPOOL ADJ CAP METAL B
35	171-5201	O RING A
36	F40-3003	CAST CONTROL CAP
37	E33-0402	SET PLT SCREW
38	B85-3101	O RING B
39	B91-1727	R/S PLT SCREW
40	F64-7201	DRIVE SHAFT WASHER A
41	B55-0301	BUSHING B
42	F88-7801	DRIVE SHAFT RET
43	F21-2201	DRIVE SHAFT RET SCREW
44	F64-7101	DRIVE SHAFT
45	E32-7701	A/R RATCHET
46	375-7103	DRIVE SHAFT WASHER B
47	F40-2501	DRIVE GEAR
48	F60-2401	DRAG WASHER A
49	B36-0303	KEY WASHER
50	E42-5401	DRAG WASHER B
51	F82-1301	GEAR SHAFT COLLAR
52	F58-0601	ROLLER CLUTCH
53	373-7810	DRAG WASHER C
54	150-8901	DRAG SPRING WASHER
55	B97-4901	HANDLE COLLAR
56	F40-3203	STAR DRAG
57	B43-3601	DRAG NUT
58	150-9001	FRICTION WASHER
59	F86-4201	HANDLE
60	B43-3601	HANDLE NUT
61	B43-3601	HANDLE NUT PLT
62	375-3003	BEARING RET WASHER

F40-2008