


Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



CONVENTIONAL REEL

SALTIST LD20H/LD30H



Key No.	Parts No.	Parts Name
1	E64-1101	Frame
2	G21-1701	Pin (A)
3	E63-9601	Click spring (A)
4	E63-9501	Click button
5	E61-7302	Click button washer
6	E63-9701	Click pawl
7	320-1402	Click pawl retainer
8	E64-0201	Click spring (B)
9	E64-0301	Frame plate
10	351-7701	Screw (A)
11	E64-9001	Spool
12	G53-6001	Ball bearing (A)
13	E57-8301	Washer (A)
14	E64-1201	Drag spring washer
15	E64-0801	Drive shaft (A)
16	E64-1401	Drive shaft retainer
17	E64-1501	Screw (B)
18	E64-1601	Drive shaft pin (A)
19	G49-8506	Ball bearing (B)
20	E64-1301	Spring (A)
21	G49-8506	Ball bearing (C)
22	E64-3001	A/R ratchet
23	E64-3401	Drag ratchet
25	E64-2801	Pinion gear
26	E17-5802	Ball bearing (D)
27	E64-1703	Right side plate
28	E64-3501	Drag pawl
29	E64-3701	Drag pawl retainer
30	E64-3801	Screw (C)
31	E64-9101	Drive shaft (B)
32	G47-2501	Ball bearing (E)
33	E64-9301	Washer (D)
34	E64-9201	Drive shaft pin (B)
35	E64-9401	Drive gear
36	E64-9501	Drive shaft nut

Key No.	Parts No.	Parts Name
37	E63-3301	Handle metal
38	E64-4501	Screw (D)
39	E64-4301	Collar (A)
40	E59-1601	Screw (E)
41	E64-4101	Washer (B)
42	E64-3902	Spring (B)
43	E64-4001	Pin (B)
44	E64-9801	Drag lever
45	E64-5001	Drag lever plate
46	E64-1501	Screw (F)
47	E64-5201	Pin (C)
48	E64-5301	Pre-set cam (A)
49	E64-5501	Pre-set cam (B)
50	171-1001	"O" ring
51	E64-5801	Drag knob spring
52	E64-5701	Pre-set click spring
53	E64-5601	Pre-set drag knob
54	G52-2801	Ball bearing (F)
55	E64-5901	Collar (B)
56-63	E65-0001	Handle assembly
64	G22-0301	Handle nut
65	G21-8201	Handle nut screw
66	E62-4501	Clamp bolt
67	E62-4401	Rod clamp
68	E62-6101	Clamp nut
69	E65-6501	Click spring (C)
70	E65-6701	Collar (C)

SALTIST LD30H Special Parts

Key No.	Parts No.	Parts Name
1	E64-8401	Frame
11	E65-0201	Spool
15	E64-8801	Drive shaft (A)
27	E64-1704	Right side plate