


SPINCASTING REEL — BW120



Key

No.	Part No.	Part Name
1	K09-9101	Front cover
2	B55-4001	Rotor nut
3	K03-8702	Rotor
4	320-0351	Spool retainer
5	370-0412	Drag washer
6	B81-1103	Spool
7	370-0412	Drag washer
8	K06-0401	Main shaft
9	K00-2601	Ball bearing
10	K00-2701	Anti-reverse pawl spring
11	K00-2801	Anti-reverse ratchet
12	402-6401	Pinion gear
13	142-7712	Main shaft spring
14	151-6731	Drag plate
15	030-6001	Click pawl
16	B93-3001	Click pawl screw
17	K06-1001	Body
18	K06-2801	Drag screw

Key

No.	Part No.	Part Name
19	B60-9202	Dial
20	K00-5501	Anti-reverse pawl
21	K00-1001	Anti-reverse pawl washer
22	B93-3001	Anti-reverse pawl screw
23	K00-1101	Anti-reverse lever
24	K00-1201	Anti-reverse lever spring
25	K00-2901	Drive gear
26	370-9900	Drive gear washer
27	K00-7001	Bushing
28	B01-3101	Bushing retainer
29	K09-9001	Side cover
30	K06-2701	Side cover screw
31	K00-6001	Handle assembly
32	160-8101	Handle lock washer
33	K00-5901	Handle lock screw
34	K00-0601	Handle screw cap
35	K00-2201	Line snubber