


## SPINNING REEL AS7050/9050



Key No.	Parts No.	Parts Name
1	6-B79-9401	Spool
2	6-B79-8601	Main shaft
3	6-320-8702	Oscillating slider retainer
4	6-B77-7302	Oscillating slider
5	6-342-5001	Rotor nut
6	6-B80-4801	Rotor
7	6-B77-6501	Bail kick lever
8	6-B77-6601	Bail kick lever cover
9	6-351-6102	Bail kick lever cover screw
10	6-B11-2801	Bail screw
11	6-B11-2701	Bail washer
12	6-B86-4601	Arm lever
13	6-352-1103	Arm lever screw
14	6-501-2001	Roller collar
15	6-250-4502	Line roller
16	6-B79-7501	Bail
17	6-352-1103	Bail holder screw
18	6-B19-7201	Bail spring
19	6-B77-6403	Bail spring cover
20	6-351-6102	Bail spring cover screw
21	6-280-5403	Ratchet
22	6-B79-7201	Pinion gear
23	6-375-9700	Rotor washer
24	6-144-0321	Anti-reverse cam spring
25	6-B80-4401	Anti-reverse cam
26	6-B80-8001	Anti-reverse claw screw
27	6-B80-4301	Anti-reverse claw plate
28	6-B79-7101	Anti-reverse claw
29	6-B79-6701	Body
30	6-B80-8101	Pinion retainer

Key No.	Parts No	Parts Name
31	6-B80-4501	Anti-reverse lever
32	6-352-2502	Anti-reverse lever screw
33	6-B79-7801	Drag washer A
34	6-B79-7901	Click gear
35	6-B77-5004	Drag washer B
36	6-B77-5202	Drag washer C
38	6-B91-3801	Drag knob spring
39	6-B79-8002	Drag screw
40	6-B79-8101	Drag washer spring
41	6-B79-8201	Drag knob
42	6-352-1103	Drag knob screw
43	6-B78-9701	Oscillating gear
44	6-B78-9801	Oscillating collar
45	6-B79-8401	Drive gear
46	6-371-2800	Drive gear washer
47	6-B07-3303	Bearing
48	6-B79-8701	Body cover
49	6-351-5904	Body cover screw
50	6-B80-4901	Handle
51	6-371-9521	Handle washer
52	6-B50-5601	Handle screw

### AS9050 special parts

1	6-B80-0001	Spool
6	6-B80-5001	Rotor
7	6-B77-9801	Bail kick lever
16	6-B79-9801	Bail
29	6-B79-6702	Body
48	6-B79-8702	Body cover