



| Key No. | Parts No. | Parts Name | Key No. | Parts No. | Parts Name |
|---------|-----------|------------------------------|---------|-----------|-------------------------|
| 1 | 6G239001 | Drag knob | 35 | 6G265401 | Bail trip lever |
| 2 | 6F373301 | Drag washer retainer | 37 | 6G194301 | Brake shoe |
| 3 | 6E467201 | Key washer | 38 | 63753002 | Washer (C) |
| 4 | 63733603 | Eared washer | 39 | 6G193701 | Screw (F) |
| 5 | 6E136001 | Drag washer | 40 | 63522501 | Screw (G) |
| 2 - 9 | 6G238801 | Spool assembly | 41 | 6G193601 | Bearing retainer |
| 2 - 9 | 6G271801 | Spool assembly (Extra spool) | 42 | 66376101 | Ball bearing (B) |
| 7 | 6B075304 | Click pawl | 43 | 6G193501 | Collar (B) |
| 8 | 6G366501 | Click spring | 44 | 6B275403 | Washer (D) |
| 9 | 63205901 | Click retainer | 45 | 6F622301 | Clutch cam retainer |
| 10 | 6E467101 | Washer (A) | 46 | 6F622201 | Clutch cam |
| 11 | 6F811501 | Click gear | 47 | 63758502 | Washer (E) |
| 12 | 6G016701 | Main shaft | 48 | 6F732501 | Spacing sleeve |
| 13 | 6G016501 | Oscillating slider | 49 | 6G220601 | Roller clutch |
| 14 | 63510315 | Screw (A) | 50 | 66341301 | Ball bearing (C) |
| 15 | 6F336102 | Rotor nut | 51 | 63758504 | Washer (F) |
| 16 | 6G194001 | Rotor | 52 | 6G193401 | Pinion gear |
| 17 | 6G195601 | Screw (B) | 53 | 6G238301 | Body |
| 18 | 6G194501 | Bail arm | 54 | 6G193101 | Anti-reverse lever |
| 19 | 6G224901 | Screw (C) | 55 | 6G193301 | Anti-reverse cam spring |
| 21 | 6F897101 | Washer (B) | 56 | 6F767700 | Washer (G) |
| 22 | 6G020801 | Ball bearing (A) | 57 | 6F677401 | Oscillating gear |
| 23 | 6F921601 | Line roller | 58 | 6G193902 | Rear cover |
| 24 | 6G047601 | Collar (A) | 59 | 6F505701 | Screw (H) |
| 25 | 6G194701 | Bail assembly | 60 | 6G016601 | Drive gear |
| 26 | 63516101 | Screw (D) | 61 | 63758500 | Washer (H) |
| 27 | 6G017504 | Bail spring shaft | 62 | 66341301 | Ball bearing (D) |
| 28 | 6G017701 | Bail spring | 63 | 6G193802 | Side cover |
| 29 | 6G017401 | Bail spring holder | 64 | 63511106 | Screw (I) |
| 30 | 6G194601 | Cover (A) | 65 | 6G259101 | Screw (J) |
| 31 | 6G205101 | Screw (E) | 66 | 6G238501 | Handle assembly |
| 32 | 6G195102 | Bail holder nut | 67 | 6F721001 | Collar (C) |
| 33 | 6G195201 | Cover (B) | 68 | 6F676503 | Screw (K) |
| 34 | 6G194101 | Bail trip lever spring | 69 | 6G256401 | WASHER (I) |