


# CROSSFIRE 1550



Key No.	Parts No.	Parts Name
5	W35-0401	SPOOL
6	W00-5101	MAIN SHAFT
8	W00-4801	ROTOR NUT
9	W35-1102	A/R PAWL SPRING A
10	W35-1202	SPRING HOLDER
11	W00-2801	BALL BEARING A
12	W35-1302	PINION GEAR
13	W35-1601	A/R PAWL SCREW
14	W35-1801	A/R PAWL
15	W35-2301	A/R PAWL SPRING B
16	W35-2701	A/R CAM
17	W00-2401	A/R CAM SPRING
18	W00-3101	BALL BEARING SCREW
19	W00-2101	A/R LEVER
20	W00-2201	A/R LEVER SCREW
21	W35-3103	BODY
22	W00-1801	DRIVE GEAR BUSHING
23	W00-1901	DRIVE GEAR
24	W00-2001	DRIVE GEAR WASHER
25	W01-5701	BALL BEARING B
26	W35-3333	SIDE COVER
27	W35-3603	HANDLE
28	W00-3901	HANDLE WASHER
29	W35-3903	HANDLE SCREW
30	W35-4001	OSC GEAR COLLAR
31	W00-1401	OSC GEAR
32	W00-1501	OSC SLIDER
33	W00-1601	OSC SLIDER RET
34	W00-1701	OSC SLIDER RET PLT SCREW
35	W35-4102	REAR COVER SCREW
36	W00-0201	DRAG WASHER A

Key No.	Parts No.	Parts Name
37	W00-0301	CLICK GEAR
38	W00-0501	EARED WASHER
39	W00-0601	KEY WASHER
40	W00-0401	DRAG WASHER B
41	W00-0701	DRAG COIL SPRING
42	W35-4201	DRAG SCREW
43	W35-4301	REAR COVER A
44	W35-4601	REAR COVER B
45	W35-4901	REAR COVER RET
46	W35-5001	DRAG KNOB
47	W35-5301	DRAG KNOB RET
48	W35-5401	O RING
49	W35-5504	ROTOR
50	W35-5901	BAIL HOLDER NUT
51	W35-6001	BAIL HOLDER SCREW
54	W35-6101	BAIL TRIP LEVER
55	W35-6201	BAIL SPRING HOLDER
56	W35-6301	BAIL SPRING
57	W35-6401	BAIL SPRING SHAFT
58	W35-6501	BAIL TRIP COVER
59	W00-4601	BAIL TRIP COVER SCREW
60	W35-6604	BAIL ARM
61	W00-5701	BAIL ARM SCREW
62	W00-5401	LINE ROLLER COLLAR
64	W35-7001	BAIL
66	W35-7401	LINE ROLLER
67	W00-5501	LINE ROLLER SCREW
69	W00-3801	SIDE COVER SCREW
70	W00-4901	ROTOR NUT HOLD PLT
81	W35-8701	DRAG WASHER C