


CROSSFIRE 3550-3iR/4050-3iR



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W45-9701	FRONT DRAG KNOB	47	W38-7901	DRAG KNOB SCREW
1-3	W55-8801	SPOOL	48	W38-8001	DRAG KNOB SCREW CAP
1-3	W55-8901	SPOOL (EXTRA)	49	W55-9101	BODY
4	W38-0302	MAIN SHAFT	50	W45-4501	HANDLE SCREW
5	W34-0201	BAIL HOLDER NUT	51	W34-4702	HANDLE COLLAR
6	W38-8101	BAIL ARM COLLAR	52	W34-2401	A/R LEVER
7	W38-0201	BAIL HOLDER SCREW	53	W38-6101	A/R LEVER SCREW
8	W45-3301	BAIL	54	W38-6201	DRAG METAL WASHER
9	W45-6601	LINE ROLLER WASHER	55	W38-6302	DRAG METAL A
10	W33-8202	LINE ROLLER BUSHING	56	W45-9001	DRAG WASHER A
11	W38-0602	LINE ROLLER	57	W38-6501	EARED WASHER
12	W33-8201	LINE ROLLER COLLAR	58	W38-6601	DRAG WASHER B
13	W51-5701	BAIL ARM	59	W38-6701	KEY WASHER
14	W46-4101	LINE ROLLER SCREW	60	W38-6801	DRAG COIL SPRING
15	W46-6201	BAIL ARM SCREW	61	W38-6901	DRAG SCREW WASHER
16	W38-1102	ROTOR NUT	62	W38-7001	DRAG SCREW
17	W46-7001	ROTOR NUT HOLD PLT SCREW	63	W38-7101	DRAG METAL B
18	W46-7101	ROTOR NUT HOLD PLT	64	W38-7201	DRAG COLLAR
19	W38-1901	BAIL SPRING COVER SCREW	65	W46-5401	DRAG COVER
20	W34-0330	BAIL SPRING COVER	66	W38-5901	CLICK LEAF SPRING B
21	W33-8702	BAIL SPRING SHAFT	67	W38-5001	CLICK LEAF SPRING RET
22	W38-2202	BAIL SPRING	68	W45-8701	OSC GEAR COLLAR
23	W33-8901	BAIL SPRING HOLDER	69	W34-2703	OSC GEAR
24	W55-9001	ROTOR	70	W38-5702	OSC SLIDER
25	W34-0501	BAIL TRIP LEVER SPRING	71	W46-5501	OSC SLIDER RET
26	W34-0602	BAIL TRIP LEVER	72	W38-5501	OSC SLIDER SCREW
27	W46-4501	BAIL TRIP LEVER WASHER	73	W46-5601	SIDE COVER SCREW A
28	W34-0703	A/R LEVER SCREW	74	W55-9201	SIDE COVER
29	W46-4601	BEARING RET SCREW	75	W38-5101	CLICK LEAF SPRING A
30	W34-0901	BEARING RET A	76	W34-3802	DRIVE GEAR
31	W34-1701	BALL BEARING A	77	W46-5801	A/R PAWL SPRING A
32	W34-1101	BEARING RET B	78	W44-1101	A/R CAM SPRING B
33	W34-1201	BEARING RET COLLAR	79	W34-3602	BALL BEARING B
34	W34-1501	ROLLER CLUTCH WASHER	80	W34-3701	DRIVE GEAR WASHER
35	W34-1401	ROLLER CLUTCH	81	W34-4401	A/R PAWL SPRING B
36	W34-1601	BALL BEARING COLLAR	82	W34-4501	A/R PAWL A
37	W46-4701	PINION GEAR COLLAR	83	W38-3801	A/R PAWL SCREW
38	W47-0601	PINION GEAR	84	W46-5901	A/R PAWL COLLAR
39	W46-4901	A/R CAM SPRING A	85	W46-6001	A/R PAWL B
40	W34-2003	A/R CAM	86	W34-4101	A/R PAWL COLLAR
41	W38-4201	SIDE COVER SCREW B	87	W34-4301	A/R PAWL SCREW
42	W46-7301	REAR COVER A	88	W51-6301	HANDLE
43	W47-3701	REAR COVER B			
44	W45-9501	REAR COVER B SCREW			
45	W38-7701	O RING			
46	W45-9601	DRAG KNOB			

4050 Special Parts

1-3	W55-9301	SPOOL
1-3	W55-9401	SPOOL (EXTRA)