




SPINNING REEL

LAGUNA2000-4000-5BI

Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	LAGUNA2500-5BI Part No.	LAGUNA3000-5BI Part No.	LAGUNA4000-5BI Part No.
1	G84-0501	DRAG KNOB	G84-0501	G84-0501	G84-0501
2	F37-3301	DRAG WASHER RET	F37-3301	F37-3301	F37-3301
3	E46-7201	KEY WASHER	E46-7201	E46-7201	E46-7201
4	E13-6001	DRAG WASHER	E13-6001	E13-6001	E13-6001
5	-	EARED WASHER	373-3603	373-3606	373-3606
2~6	Q20-3001	SPOOL ASSEMBLY	Q19-6401	Q21-9601	Q20-6601
7	E39-8000	WASHER	E39-8000	E39-8000	E39-8000
8	E46-7101	WASHER	E46-7101	E46-7101	E46-7101
9	G83-9301	CLICK GEAR	G83-9301	G83-9301	G83-9301
10	H11-8501	WASHER	H11-8501	H11-8501	H11-8501
11	Q12-2401	ROTOR NUT	Q12-2401	Q12-2401	G12-3301
12	G62-7701	SCREW	G62-7701	G62-7701	G62-7701
13	Q20-2801	ROTOR	Q20-3301	Q20-3301	G84-4153
14	G19-5602	SCREW	G19-5602	G19-5602	G19-5602
15	G20-5001	SCREW	G20-5001	G20-5001	G20-5001
16	H21-8601	BAIL ASSEMBLY	H22-2501	H22-2501	H22-3201
17	Q20-3401	COLLAR	Q20-3401	Q20-3401	Q20-3401
18	F62-5005	LINE ROLLER	F62-5005	F62-5005	F62-5005
19	G87-4301	COLLAR	G87-4301	G87-4301	G87-4301
20	G15-2502	COLLAR	G15-2502	G15-2502	G84-4303
21	G27-0801	SCREW	G27-0801	G27-0801	G27-0801
22	Q27-3602	ARM LEVER COVER	Q27-3702	Q27-3702	G84-4303
23	G83-8801	BAIL ARM	G83-8801	G83-8801	G83-8801
24	F77-7901	BAIL SPRING	F80-0701	F80-0701	F80-0701
25	G86-1201	BAIL TRIP LEVER	G84-2001	G84-2001	G84-4201
26	G83-7101	SCREW	G83-7101	G83-7101	G83-7101
27	Q19-6201	SEALED CAP	Q19-6201	Q19-8301	Q20-6401
28	Q30-8301	ROLLER CLUTCH	Q30-8301	Q30-8301	J01-5701
29	Q19-6101	CLUTCH RING	Q19-6101	Q19-6101	Q20-6301
30	Q19-5701	SCREW	Q19-5701	Q19-5701	Q19-5701
31	Q19-5601	PINION BEARING PLT	Q19-5601	Q19-5601	Q20-5901
32	G46-7302	BALL BEARING	G46-7302	G46-7302	H73-5002
33	Q22-8502	PINION GEAR	Q22-8501	Q22-8501	Q23-0701
34	Q16-1701	COLLAR	Q16-1701	Q16-1701	Q17-5201
35	G27-0801	SCREW	G27-0801	G27-0801	G27-0801
36	Q17-3902	REAR COVER	Q16-2402	Q16-2402	Q17-5602
37	G11-5001	SCREW	G11-5001	G11-5001	G11-5001
38	Q20-2601	BODY COVER	Q19-5901	Q19-5901	Q20-6101
39	G46-7302	BALL BEARING	G46-7302	G46-7302	G52-3405
40	375-8500	DRIVE GEAR WASHER	375-8500	375-8500	373-7800
41	G47-2401	BEARING RET	G47-2401	G47-2401	G52-5101
42	G52-2706	BALL BEARING	G52-2706	G52-2706	B86-1705
43	Q16-2201	DRIVE GEAR	Q16-2201	Q16-2201	Q17-5301
44	Q17-3501	MAIN SHAFT	Q16-1401	Q16-1401	Q20-5701
45	Q19-5501	SCREW	Q19-5501	Q19-5501	H46-3401
46	G46-9005	BALL BEARING	G46-9005	G46-9005	G46-7105
47	H12-9200	WASHER	H12-9200	H12-9200	G52-2100
48	H77-0601	O RING	H77-0601	H77-0601	B85-3101
49	Q20-2501	OSC GEAR	Q19-5401	Q19-5401	Q20-5601
50	H69-7801	A/R CAM SPRING	H69-7801	H69-7801	H69-7801
51	Q11-8101	A/R CAM	Q11-8101	Q11-8101	Q13-3401
52	Q11-8001	A/R LEVER	Q11-8001	Q11-8001	Q11-8001
53	Q20-2201	BODY	Q19-5101	Q19-5101	Q20-5301
54	Q13-2401	HANDLE SCREW	Q13-2401	Q13-2401	Q13-6101
55	160-8401	LOCK WASHER	160-8401	160-8401	160-8401
56	F72-1001	HANDLE COLLAR	F72-1001	F72-1001	F72-1202
57	Q20-2901	HANDLE ASSEMBLY	Q19-6301	Q19-6301	Q20-6501