




SPINNING REEL

OPUS PLUS 4500A/5000A



KEY NO.	PARTS NAME	PARTS NO.	KEY NO.	PARTS NAME	PARTS NO.
1	Drag Knob Assembly	WD0-7401	46	Body	WD1-0801
2	Spool Assembly	WD0-7501	47	Handle Screw	WD1-0901
3	Washer	WD0-7601	48	Collar	W34-4701
4	Click gear	WD0-7701	49	Rear Cover	WD1-1001
5	Main Shaft	WD0-7801	50	Screw	WD1-1101
6	Screw	WD0-7901	51	Ball Bearing	W78-0001
7	Bail Assembly	WD0-8001	52	Oscillating Gear	WD1-1201
8	Washer	WD0-8101	53	Bushing	WD1-1301
9	Bushing	W57-9501	54	Screw	W75-5801
10	Line Roller	WD0-8201	55	Washer	W36-2601
11	Collar	W33-8202	56	Bushing	W36-1101
12	Bail Arm	WD0-8301	57	Washer	WD1-1401
13	Screw	W33-8301	58	Oscillation Slider	WD1-1501
14	Screw	WD0-7901	59	Stabilizer bar	WD1-1601
15	Screw	W34-0401	60	Screw	WD1-1701
16	Rotor Cover (A)	WD0-8401	61	Screw	W75-4601
17	Bail Spring Shaft	WD0-8501	62	Spring	WD1-1801
18	Bail Spring	WD0-8601	63	Screw	WD1-1901
19	Bail Spring Holder	W77-1201	64	Anti-Reverse Pawl Plunger	WD1-2001
20	Bail Shaft	WD0-8701	65	Screw	WD1-2101
21	Screw	W34-0703	66	Collar	W34-4101
22	Rotor Nut Holding Plate	W30-6501	67	Anti-reverse Pawl	WD1-2201
23	Rotor Nut	WD0-8801	68	Screw	W34-4301
24	Rotor	WD0-8901	69	Ball Bearing	W28-0100
25	Rotor Cover (B)	WD0-9001	70	Spring	WD1-2301
26	Screw	W34-0401	71	Drive Gear	WD1-2401
27	Collar	WD0-9101	72	Washer	W75-4201
28	Screw	WD0-9201	73	Side Cover	WD1-2501
29	Bearing Retainer	WD0-9301	74	Screw	W75-4501
30	Ball Bearing	WD0-9401	75	Screw	W75-4601
31	Collar	WD0-9501	76	Handle Assembly	WD1-2601
32	Collar	WD0-9601	77	Washer	WD1-2701
33	Washer	W75-1601	78	Collar	WD1-2801
34	Roller Clutch	WD0-9701	79	Screw	W45-0301
35	Collar	WD0-9801			
36	Pinion Gear	WD0-9901			
37	Screw	WD1-0001			
38	Anti-reverse Pawl	WD1-0101			
39	Anti-reverse Pawl Spring	WD1-0201			
40	Anti-reverse Cam Spring	WD1-0301			
41	Anti-reverse Cam	WD1-0401			
42	O-ring	WD1-0501			
43	Screw	W75-3301			
44	Anti-reverse Lever	WD1-0601			
45	Screw	WD1-0701			
46	Body	WD1-0801			
47	Handle Screw	WD1-0901			
48	Collar	W34-4701			
49	Rear Cover	WD1-1001			
50	Screw	WD1-1101			
51	Ball Bearing	W78-0001			
52	Oscillating Gear	WD1-1201			
53	Bushing	WD1-1301			
54	Screw	W75-5801			
55	Washer	W36-2601			
56	Bushing	W36-1101			
57	Washer	WD1-1401			
58	Oscillation Slider	WD1-1501			
59	Stabilizer bar	WD1-1601			
60	Screw	WD1-1701			
61	Screw	W75-4601			
62	Spring	WD1-1801			
63	Screw	WD1-1901			
64	Anti-Reverse Pawl Plunger	WD1-2001			
65	Screw	WD1-2101			
66	Collar	W34-4101			
67	Anti-reverse Pawl	WD1-2201			
68	Screw	W34-4301			
69	Ball Bearing	W28-0100			
70	Spring	WD1-2301			
71	Drive Gear	WD1-2401			
72	Washer	W75-4201			
73	Side Cover	WD1-2501			
74	Screw	W75-4501			
75	Screw	W75-4601			
76	Handle Assembly	WD1-2601			
77	Washer	WD1-2701			
78	Collar	WD1-2801			
79	Screw	W45-0301			

OPUS PLUS 5000A SPECIAL PART LIST		
KEY NO.	PARTS NAME	PARTS NO.
2	Spool Assembly	WD0-7502
7	Bail Assembly	WD0-8002
16	Rotor Cover (A)	WD0-8402
20	Bail Shaft	WD0-8702
24	Rotor	WD0-8902
25	Rotor Cover (B)	WD0-9002
46	Body	WD1-0802
73	Side Cover	WD1-2502