


# SPINNING REEL

# REGAL-X3505T



Key No.	Parts No.	Parts Name
2-9	F49-3701	Spool assembly
1	F42-1906	Drag knob
2	F37-3301	Drag washer retainer
3	F09-4901	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F49-3801	Spool assembly
7	b07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	F09-4701	Spool washer
11	E46-2701	Click gear
12	F48-0002	Main shaft
13	F09-1301	Oscillating slider
14	352-1502	Oscillating slider screw
15	340-6602	Rotor nut
16	F42-1806	Rotor assembly
17	B67-9308	Line roller screw
18	F45-2702	Bail arm
19	E49-3501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F44-6302	Line roller collar
22	F44-6201	Line roller washer
23	F47-3401	Line roller bushing
24	F45-4902	Line roller
25	F49-4301	Bail assembly
26	B84-2102	Bail trip cam screw
27	E46-2101	Bail trip lever
28	F18-0006	Trigger lever
29	E36-9901	Trigger spring

Key No.	Parts No.	Parts Name
30	E41-7801	Trigger screw
31	F12-8901	Bail spring
32	F31-4506	Bail spring cover
33	E24-8101	Bail spring cover screw
34	F31-4606	Bail trip cover
35	E46-2001	Anti-reverse pawl spring A
36	F24-8901	Anti-reverse ratchet
37	L03-6502	Ball bearing A
38	E52-0101	Pinion gear
39	F49-3502	Body assembly
40	E00-7101	Anti-reverse pawl screw
41	E46-1302	Anti-reverse pawl
42	E46-1201	Anti-reverse pawl spring B
43	E03-7801	Bearing retainer screw
44	E32-7801	Anti-reverse cam spring
45	F08-5124	Anti-reverse lever
46	F13-1601	Oscillating gear collar
47	F21-6601	Oscillating gear
48	E52-0201	Drive gear
49	373-7805	Drive gear washer
50	631-6901	Ball bearing B
51	F49-3602	Side rover
52	B83-5002	Side cover screw A
53	E15-8602	Side cover screw B
54	F50-4001	Handle assembly
55	F43-3501	Handle collar
56	692-5011	Hand e lock screw
57	F40-1001	Bail holder washer