


SPINNING REEL

REGAL-Z1500T/2000T



Key No.	Parts No.	Parts Name
2-9	F46-1501	Spool assembly
1	F32-8505	Drag knob
2	F37-3301	Drag washer retainer
3	E46-7201	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F46-1601	Spool assembly
7	B07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	E46-7101	Spoolwasher
11	270-6501	Click gear
12	F46-0801	Main shaft
13	F12-2301	Oscillating slider
14	351-0311	Oscillating slider screw
15	341-9201	Rotor nut
16	F32-7804	Rotor assembly
17	B67-9308	Line roller screw
18	F46-1101	Bail arm
19	B84-2102	Bail arm screw
20	F44-6302	Line roller collar
21	F44-6201	Line roller washer
22	F05-5601	Ball bearing A
23	F45-4902	Line roller
24	F46-1201	Bail assembly
25	E49-6401	Bail trip lever
26	E49-6801	Bail spring
27	F32-4204	Bail spring cover
28	E24-8101	Bail spring cover screw
29	F32-6304	Bail trip cover
30	F12-2101	Anti-reverse pawl spring
31	F32-7701	Anti-reverse ratchet
32	634-1301	Ball bearing B

Key No.	Parts No.	Parts Name
33	F12-1601	Pinion gear
34	F47-3301	Body assembly
38	F12-5701	Anti-reverse pawl screw
39	F12-1901	Anti-reverse pawl
40	F12-3501	Anti-reverse pawl collar
41	F12-3401	Anti-reverse pawl spring
42	E03-7801	Bearing retainer screw
43	F12-2001	Anti-reverse cam spring
44	F08-5123	Anti-reverse lever
45	F12-2201	Oscillating gear
46	E50-5801	Bearing washer
47	E30-6801	Ball bearing C
48	F12-1501	Drive gear
49	375-8507	Drive gear washer
50	634-1301	Ball bearing
51	F46-0901	Side cover
52	E15-8602	Side cover screw
53	F40-4801	Handle collar
54	B92-5010	Handle lock screw
55	F50-7401	Handle assembly

Z2000T SPECIAL PARTS

Key No.	Parts No.	Parts Name
2-9	F47-4301	Spool assembly
6	F47-4401	Spool assembly
16	F33-1804	Rotor assembly
24	F47-4101	Bail assembly
25	E49-6501	Bail trip lever
34	F47-3302	Body assembly
51	F46-0903	Side cover