



Key No.	Parts No.	Parts Name
2-9	G01-8901	SPOOL
2-9	G10-0201	EXTRA SPOOL
1	F77-7606	DRAG KNOB
2	F37-3301	DRAG WASHER RET
3	E46-7201	KEY WASHER
4	E13-6001	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	E46-7101	SPOOL WASHER
11	F81-1501	CLICK GEAR
12	G01-6701	MAIN SHAFT
13	G01-6501	OSC SLIDER
14	351-0315	OSC SLIDER SCREW
15	F33-6102	ROTOR NUT
16	G01-7101	ROTOR
17	G01-8601	LINE ROLLER SCREW
18	G01-7801	BAIL ARM
19	B84-2102	BAIL HOLDER SCREW
20	F89-7101	LINE ROLLER WASHER
21	G02-0801	BALL BEARING A
22	F62-5001	LINE ROLLER
23	G01-8001	BAIL
24	G01-7501	BAIL SPRING SHAFT
25	G01-7701	BAIL SPRING
26	G01-7401	BAIL SPRING HOLDER
27	G01-7901	BAIL SPRING COVER
28	E36-4202	BAIL SPRING COVER SCREW
29	G01-8501	BAIL HOLDER COVER
30	E24-7402	BAIL HOLDER COVER SCREW
31	G01-6401	BEARING RET A

Key No.	Parts No.	Parts Name
32	F22-6701	BALL BEARING B
33	F67-7301	ROLLER CLUTCH RET
34	375-8509	ROLLER CLUTCH WASHER
35	G03-6901	BEARING RET B
36	F73-2501	SPACING SLEEVE
37	F62-2001	ROLLER CLUTCH
38	634-1301	BALL BEARING C
40	375-8504	PINION WASHER
41	G01-6201	PINION GEAR
42	G01-7201	BAIL TRIP LEVER SPRING
43	G01-7301	BAIL TRIP LEVER
44	E24-8101	BAIL TRIP LEVER SCREW
45	G01-6601	DRIVE GEAR
46	375-8500	DRIVE GEAR WASHER
47	634-1301	BALL BEARING D
48	G01-6801	SIDE COVER
49	F72-1001	HANDLE COLLAR
50	F67-6503	HANDLE SCREW
51	E15-8602	SIDE COVER SCREW A
52	E13-0502	SIDE COVER SCREW B
53	F67-7401	OSC GEAR
54	G01-5901	A/R CAM
55	G01-6101	A/R CAM SPRING
56	G01-5801	A/R LEVER
57	G01-6001	A/R LEVER SCREW
58	E24-8103	REAR COVER SCREW
59	G01-6901	REAR COVER
60	G01-5601	BODY
61	G02-0001	HANDLE
62	F76-7700	OSC GEAR WASHER
63	F40-1001	BAIL HOLDER WASHER