


## SPINNING REEL — ST1305



Key No. 2.70-73  
E27-2204 Spool assembly

Key No.	Part No.	Part Name
1	E27-2802	Drag knob
2	E27-2304	Spool assembly
3	375-4200	Spool washer
4	E12-2303	Click leaf spring holder
5	B74-7702	Spool click leaf spring
6	E39-4001	Main shaft washer
9	E36-5301	Click gear
10	E48-0201	Main shaft
11	341-9201	Rotor nut
12	E36-8001	Rotor
13	B67-9304	Line roller screw
14	E36-9501	Bail arm
15	E36-9601	Bail arm screw
16	320-5901	Bail arm screw retainer
17	B55-4301	Line roller washer
18	B45-1501	Line roller collar
19	250-3921	Line roller
20	E37-1401	Bail assembly
21	E00-7101	Bail trip cam screw
22	E36-4401	Bail spring shaft
23	E39-0601	Ball spring
24	E36-9801	Trigger lever
25	E36-9901	Trigger spring
26	E41-7801	Trigger screw
27	E36-9703	Bail spring cover
28	E36-4201	Bail spring cover screw
29	E36-5002	Bail trip lever
30	E36-5103	Bail trip cover
31	375-8503	Bearing washer
32	L03-6601	Ball bearing A
33	F03-7501	Anti-reverse ratchet
34	E41-7001	Pinion gear
35	E24-3301	Pinion collar
36	E48-0301	Body assembly
37	E03-7801	Bearing retainer screw
38	E26-8701	Anti-reverse cam spring

Key No.	Part No.	Part Name
39	E36-3211	Anti-reverse lever
40	B33-9801	Worm shaft gear retainer
41	E41-7101	Worm shaft gear
42	E39-3501	Worm shaft bush
43	E27-1601	Worm shaft
44	F02-4301	Oscillating slider
45	E19-1202	Oscillating pawl
46	E19-1301	Oscillating pawl bush
47	375-0800	Oscillating pawl washer
48	E24-4901	Oscillating slider cover
49	E15-0203	Oscillating slider cover screw
50	375-4100	Worm shaft washer
51	E36-3801	Worm shaft retainer
52	E39-3601	Worm shaft collar
53	E36-7508	Rear cover
54	B95-9301	Anti-reverse pawl plate
55	E27-1301	Anti-reverse pawl
56	B95-9501	Anti-reverse pawl collar
57	B95-9602	Anti-reverse pawl spring A
58	B00-8601	Anti-reverse pawl screw
59	E24-5301	Anti-reverse pawl spring B
60	F00-7101	Drive gear
61	375-8501	Drive gear washer
62	E36-7404	Side cover
63	E15-8601	Side cover screw A
64	E15-8602	Side cover screw B
65	E11-9601	Side cover screw C
66	E41-7901	Handle assembly
67	F02-0201	Handle lock washer
68	F03-5601	Handle lock screw
69	634-1301	Ball bearing B
70	171-7701	Drag washer retainer
71	E13-6101	Key washer
72	E13-6001	Drag washer
73	E13-6201	Eared washer