




# BAITCASTING REEL

# LEXA-LC100H

Please order by parts number, not key number  
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	330-3060	CLICK BUTTON	48	540-6020	WASHER
2	701-2480	LEFT SIDE PLATE	49	510-4430	YOKE SPRING
3	190-1271	CLICK PAWL	50	260-1673	PINION GEAR
4	200-0530	RETAINER	51	140-1280	BALL BEARING
5	540-5990	SPACER	52	200-0580	RETAINER
6	410-3380	PLATE	53	410-2211	DRIVE SHAFT PLATE
7	460-2930	SCREW	54	540-6600	WASHER
8	510-6330	CLICK SPRING	55	470-3081	DRIVE SHAFT
9	460-7470	SET PLATE SCREW	56	460-4640	SCREW
10	240-3250	COG WHEEL	57	540-7010	WASHER
11	210-2580	COLLAR	58	530-0840	A/R PAWL
12	460-7460	SCREW	59	240-2530	A/R RATCHET
13	220-3160	SET PLATE	60	540-6840	WASHER
14	200-0530	RETAINER	61	250-1400	DRIVE GEAR
15	240-3090	SPOOL GEAR	62	540-6950	DRAG WASHER
16	140-2340	BALL BEARING	63	540-9031	KEY WASHER
17-20	701-2510	SPOOL ASSEMBLY	64	150-2190	GEAR SHAFT COLLAR
21	110-1074	FRAME	65	140-1810	ROLLER CLUTCH
22	410-2140	CLUTCH LEVER PLATE	66	701-2490	RIGHT SIDE PLATE
23	410-2150	CLUTCH LEVER PLATE	67	430-1080	O'RING
24	090-0260	CLUTCH LEVER	68	150-2060	BUSHING
25	490-1080	LINE GUIDE	69	430-1061	BEARING RETAINER
26	400-2540	LINE GUIDE PAWL	70	540-6850	SPACER
27	540-3980	WASHER	71	540-4340	SPACER
28	380-0780	LINE GUIDE NUT	72	380-2020	CAST CONTROL CAP
29	270-0720	LEVEL LINE GUARD	73	240-2820	COUNTER GEAR
30	470-4580	WORM SHAFT	74	460-5390	SCREW
31	240-3260	WORM SHAFT GEAR	75	550-6100	COUNTER ASSEMBLY
32	471-8720	SHAFT	76	701-2470	COUNTER COVER
33	240-3290	WORM SHAFT GEAR	77	460-4870	SCREW
34	210-2630	COLLAR	78	460-6030	SCREW
35	200-1440	RETAINER	79	460-4300	SCREW
36	550-4004	FRONT PLATE	80	460-7480	LONG SCREW
37	460-5170	LONG SCREW	81	140-0570	BALL BEARING
38	540-6060	WORM SHAFT WASHER	82	540-6250	WASHER
39	210-2620	COLLAR	83	510-5370	CLICK LEAF SPRING HOLDER
40	240-3200	WORM SHAFT GEAR	84	540-6391	WASHER
41	200-0530	RETAINER	85	540-9021	WASHER
42	170-1280	CLUTCH CAM	86	701-2500	STAR DRAG
43	330-2820	CLUTCH TRIP PLATE	87	510-3260	LEAF SPRING
44	510-6370	CLUTCH TRIP PLATE SPRING	88	701-2520	HANDLE ASSEMBLY
45	510-6300	SPRING	89	380-0770	HANDLE NUT
46	460-1290	SCREW	90	180-2470	HANDLE NUT PLATE
47	410-2880	YOKE	91	460-0450	HANDLE NUT PLATE SCREW