




BAITCASTING REEL

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

LEXA-WN400H/HS-P/PWR-P



Key No.

Part No.

Part Name

1	460-5620	SET PLATE SCREW
2	510-4450	SET PLATE SPRING
3	550-1700	BRAKE ADJ KNOB
4	510-5340	BRAKE CLICK SPRING
5	200-0530	BRAKE DIAL RETAINER
6	540-5380	WASHER
7	230-256B	LEFT SIDE PLATE
8	410-2720	BRAKE DIAL RETAINER B
9	230-2570	SET PLATE
10	460-3220	SET PLT SCREW
11	240-2290	MAGNET HOLDER
12	430-1070	MAGNET HOLDER RETAINER
13	540-8120	SPACER
14	540-8110	SPACER A
15	140-1790	BALL BEARING
16	430-0440	BARING RETAINER
17-20	701-3020	SPOOL ASSEMBLY
21	110-2021	FRAME
22	410-2680	SPACER
23	410-2670	SPACER
24	090-0290	CLUTC LEVER
25	400-2570	PIN
26	510-5310	SPRING
27	400-2720	PIN
28	170-1370	CLUTCH CAM
29	410-2690	CLUTCH CAM PLATE
30	400-3310	KICK LEVER PIN
31	330-2940	KICK LEVER
32	210-2410	BUSHING
33	200-0570	E-CLIP
34	510-5290	KICK LEVER SPRING
35	510-5300	SPRING
36	460-1290	SCREW
37	410-2711	YOKE
38	540-5380	WASHER
39	510-6040	YOKE SPRING
40	260-2001	PINION GEAR
41	701-3000	LINE GUIDE
42	400-2540	LINE GUIDE PAWL
43	540-3980	WASHER
44	380-0780	LINE GUIDE NUT
45	270-0870	LEVEL WIND GUARD
46	150-1050	BUSHING
47	470-2430	WORM SHAFT
48	240-2300	WORM SHAFT GEAR
49	200-0530	RETAINER
50	550-1711	FRONT PLATE
51	150-2260	BUSHING
52	200-0580	RETAINER
53	460-5320	LONG SCREW
54	400-3380	PILLAR
55	200-1160	E-CLIP
56	140-2030	BALL BEARING
57	540-7220	WASHER

Key No.

Part No.

Part Name

58	200-0580	RETAINER
59	410-2700	DRIVE SHAFT PLATE
60	460-5290	SCREW
61	460-5370	SCREW
62	540-6600	WASHER
63	240-2260	OSC GEAR
64	470-2422	DRIVE SHAFT PLATE
65	530-0860	A/R PAWL
66	240-3030	A/R RATCHET
67	540-6670	WASHER
68	250-1550	MAGNET HOLDER
69	540-7100	WASHER
70	540-8060	WASHER
71	540-9890	WASHER
72	540-8100	KEY WASHER
73	540-8090	DRAG WASHER
74	540-8070	KEY WASHER
75	150-2270	GEAR SHAFT COLLAR
76	140-2000	ROLLER CLUTCH
77	701-3010	RIGHT SIDE PLATE
78	150-2060	BUSHING
79	430-1061	BEARING RETAINER
80	430-1000	O'RING
81	540-6460	WASHER
82	540-5980	SPACER
83	380-1991	CAST CONTROL CAP
84	460-5790	SCREW
85	460-7430	SCREW
86	460-4870	SCREW
87	140-2040	BALL BEARING
88	540-6250	WASHER
89	510-5370	CLICK LEAF SPRING HOLDER
90	540-6391	WASHER
91	540-9021	WASHER
92	700-7340	STAR DRAG
93	510-3260	LEAF SPRING
94	701-3030	HANDLE ASSEMBLY
95	380-1441	HANDLE NUT
96	410-2500	HANDLE NUT PLATE
97	460-4260	HANDLE LOCK SCREW

LEXA-WN400HS-P SPECIAL PARTS

Key No.	Part No.	Part Name
98	260-2031	PINION GEAR
99	701-3070	RIGHT SIDE PLATE
100	250-1540	DRIVE GEAR
104	701-3040	HANDLE ASSEMBLY

LEXA-WN400PWR-P SPECIAL PARTS

Key No.	Part No.	Part Name
101	260-2041	PINION GEAR
102	701-3060	RIGHT SIDE PLATE
103	250-1580	DRIVE GEAR
104	701-3040	HANDLE ASSEMBLY