


BAITCASTING REEL

MILLIONAIRE-CV-X103LA



Key No.	Parts No.	Parts Name
1	G00-2202	R/S OUTER RING
2	G00-1301	BEARING RET A
3	G06-7702	R/S PLT
4	G00-2301	O RING A
5	F79-8001	BRAKE CLICK SPRING
6	G00-2401	BRAKE ADJ KNOB
7	375-7404	SPACER A
8	375-7411	SPACER B
9	F57-4303	SPACER C
10	E08-8003	BALL BEARING A
11	E21-9701	BEARING RET B
12-20	Z01-2021	SPOOL
21	G13-4401	FRAME
22	G00-0202	CLUTCH LEVER PLT A
23	G00-0404	CLUTCH LEVER
24	G00-0302	CLUTCH LEVER PLT B
25	F79-3401	CLUTCH CAM RET
26	B86-1702	BALL BEARING B
27	F99-7401	CLUTCH CAM
28	G06-7201	YOKE PLT
29	F79-3801	CLUTCH CAM SCREW
30	F99-8101	CLUTCH SPRING
31	F79-4401	PIN A
32	G06-7301	CLUTCH TRIP PLT
33	F79-4701	CLUTCH TRIP PLT SPRING
34	F79-4601	PIN B
35	371-6905	CLUTCH TRIP PLT WASHER
36	320-1402	CLUTCH TRIP PLT RET
37	F99-8201	YOKE
38	F79-4901	YOKE SPRING
39	F99-8401	PINION GEAR
40	E21-9701	BEARING RET C
41	F64-8301	BUSHING A
42	G13-4303	L/S PLT
43	B67-9304	L/S PLT SCREW
44	F80-0501	PINION SHAFT

Key No.	Parts No.	Parts Name
45	171-5201	O RING B
46	B17-5401	SPOOL ADJ CAP METAL
47	B17-5503	SPACER
48	F57-4403	CAST CONTROL CAP
49	B86-4101	STABILIZER BAR RET
50	F97-3201	STABILIZER BAR
52	320-5901	WORM SHAFT RET
53	373-1303	WORM SHAFT WASHER
54	F79-5801	WORM SHAFT HOLDER A
55	F79-5101	LEVEL WIND GUARD
56	G05-0402	LINE GUIDE
57	F96-6001	LINE GUIDE PAWL
58	F40-2803	PAWL CAP
59	F79-5501	WORM SHAFT HOLDER B
60	F84-9102	WORM SHAFT
61	F57-5601	DRIVE SHAFT WASHER
62	B55-0301	BUSHING B
63	G02-2502	DRIVE SHAFT
64	G06-7601	DRIVE SHAFT RET
65	E13-4501	DRIVE SHAFT RET SCREW
66	F76-1701	A/R RATCHET
67	G00-1501	DRIVE GEAR A
68	G06-8001	DRIVE GEAR B
69	F79-6101	EARED WASHER
70	F96-7801	DRAG WASHER
71	F79-6301	KEY WASHER A
72	G14-1801	KEY WASHER B
73	150-8901	DRAG SPRING WASHER
74	G14-1901	GEAR SHAFT COLLAR
75	F99-9801	ROLLER CLUTCH
76	G05-2801	DRAG COLLAR
77	G05-0602	STAR DRAG
78	F85-0401	FRICTION WASHER
79	G05-0701	HANDLE
80	F84-9902	HANDLE NUT
81	F85-0004	HANDLE NUT RET