


## BAITCASTING REEL PMA10S/15S



Key No.	Parts No.	Parts Name
1	B54-1208	Left side cover
2	B36-0401	Left side cover screw
3	B66-1001	Brake adjusting knob
4	637-0601	"O" ring
5	B54-1701	Brake adjusting gear
6	320-4202	Brake adjusting gear retainer
7	B87-1001	Frame
8	320-5901	Worm shaft retainer
9	376-1801	Worm shaft holder washer
10	B71-5601	Worm shaft holder
11	B57-8701	Line guide
12	B71-0101	Line guide pin
13	375-4100	Line guide nut
14	342-4801	Line guide washer
15	371-5401	Worm shield
16	B87-1301	Worm shaft
17	B36-3401	Frame post
18	B66-1201	Magnet holder
19	B54-3201	Magnet holder ret. ring
20	375-7400	Bearing metal washer
21	B55-0301	Bearing
22	B42-1601	Bearing retainer
23	B54-3304	Spool
24	B42-1601	Bearing retainer
25	B55-0301	Bearing
26	B87-0801	Set plate
27	B68-2801	Anti-reverse claw
28	B35-8901	Clutch spring
29	B81-5503	Set plate spring
30	320-1402	Clutch ret. ring
31	B35-9001	Pinion yoke
32	144-7101	Pinion yoke spring
33	B87-0901	Pinion gear

Key No.	Parts No.	Parts Name
34	B71-2107	Right side cover
35	B64-3101	Bush
36	B17-5401	Spool adjusting cap metal A
37	B17-5501	Spool adjusting cap metal B
38	171-5201	"O" ring
39	B35-7305	Right spool cap
40	B36-0401	Right side cover screw
41	373-7611	Gear shaft washer A
42	B35-9602	Gear shaft
43	B35-9701	Ratchet
44	375-7102	Gear shaft washer B
45	B85-2101	Drive gear
46	B36-0202	Drag washer A
47	B36-0301	Drag washer B
48	373-7803	Drag washer C
49	150-8901	Spring washer
50	634-5801	Spacing sleeve
51	B36-0504	Star drag
52	150-9001	Handle washer
53	B46-5801	Handle
54	B41-1701	Handle nut washer
55	320-8202	Handle nut retainer
56	B43-3601	Handle nut
57	B43-3903	Handle nut plate
58	351-1801	Handle nut plate screw

### PMA15S Special Parts

7	B87-1801	Frame
15	B71-5501	Worm shield
16	B87-2201	Worm shaft
17	B36-4401	Frame post
23	B54-5904	Spool
34	B71-2108	Right side cover