


BAITCASTING REEL

TATULA CT-R 100HL/100HSL/100XSL



		B 11			
Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1 2	H93-0401	SET PLT SCREW	62 63	121-4212	LINE GUIDE PAWL
	E16-7101	SPRING	63 64	373-1300	WASHER
3	H93-0234	BRAKE ADJ KNOB		F40-2801	PAWL CAP
4	B33-9801	RETAINER	65	J24-7601	LEVEL WIND GUARD
5	F63-7701	BRAKE DIAL WASHER	66	J24-3601	WORM SHAFT
6	H66-3401	BRAKE CLICK SPRING	67	G72-0001	WORM SHAFT BEARING
7	H94-4913	R/S PLT	68	H91-0501	WORM GEAR
8	H91-5501	BRAKE DIAL RET	69	B33-9801	RETAINER
9	G93-9301	SCREW	70	G09-9800	WASHER
10	H93-0502	MAGNET HOLDER	71	320-8002	RETAINER
11	375-7400	SPACER	72	B35-8607	BALL BEARING
12	375-7411	SPACER	73	H92-8901	PLATE
13	G18-5101	SPACER	74	E13-4509	SCREW
14	G51-1507	BALL BEARING	75	H91-2701	DRIVE SHAFT GEAR
15	F03-2201	BEARING RET	76	J34-2202	DRIVE SHAFT
16-24	Z02-2839	SPOOL ASSEMBLY	77	H92-9401	A/R RATCHET
25	J33-8003	FRAME	78	J08-5101	DRIVE SHAFT WASHER
26	J24-4006	FRONT PLT	79	H94-4802	DRIVE GEAR
27	H84-2803	SCREW	80	H45-2602	DRAG WASHER
28	J33-5001	CLUTCH LEVER	81	H91-3201	KEY WASHER
29	H91-5701	CLUTCH LEVER PLT	82	J37-7801	GEAR SHAFT COLLAR
30	H91-5601	CLUTCH LEVER PLT	83	G81-9801	ROLLER CLUTCH
31	J24-4101	STABILIZER BAR	84	B86-1704	BALL BEARING
32	H70-4101	RETAINER	85	B55-3801	WASHER
33	H91-0601	COLLAR	86	F02-8203	CLICK LEAF SPRING HOLDER
34	H92-8801	SPRING	87	F03-2401	CLICK LEAF SPRING
35	J05-5201	PIN	88	150-8901	SPRING WASHER
36	B86-1704	BALL BEARING	89	H92-9501	WASHER
37	J24-7401	PLATE (A)	90	J14-1002	NUT
38	H29-4101	SCREW	91	J01-1901	SPRING C
39	J24-7501	CLUTCH CAM SPRING	92	J14-0001	STAR DRAG
40	J22-1501	CLUTCH TIRP LEVER	93	F57-6601	HANDLE COLLAR
41	J24-7201	CLUTCH CAM	94	J14-2801	HANDLE ASSEMBLY
42	H15-9201	WASHER	95	G79-3302	HANDLE NUT
43	352-2501	SCREW	96	H83-4512	HANDLE NUT PLT
44	H65-9101	CLUTCH CAM PLT	97	353-8301	HANDLE NUT PLT SCREW
45	B03-2904	SCREW			
46	H94-4401	YOKE		TACT-R100	HS SPECIAL PARTS
47	H58-2001	YOKE SPRING	Key No.	Part No.	Part Name
48	H94-4701	PINION GEAR	3	H93-0220	BRAKE ADJ KNOB
49	H18-0501	BEARING RET	48	J00-4301	PINION GEAR
50	G43-1105	BALL BEARING	51	J21-4410	L/S PLT
51	J21-4409	L/S PLT	79	J00-4102	DRIVE GEAR
52	B05-5201	O-RING	96	H83-4504	HANLDE NUT PLT
53	J21-3101	SPACER			
54	B17-5503	WASHER		TACT-R100	XS SPECIAL PARTS
55	J28-8202	CAST CONTROL CAP	Key No.	Part No.	Part Name
56	G04-0814	SIDE PLT SCREW	3	H93-0218	BRAKE ADJ KNOB
57	G04-0801	SCREW	48	J01-1301	PINION GEAR
58	320-5901	RETAINER	51	J21-4411	L/S PLT
59	B41-1700	WASHER	79	J01-1402	DRIVE GEAR
60	G72-0001	WORM SHAFT BEARING	96	H83-4506	HANDLE NUT PLT
61	J24-3303	T-LEVEL WIND			