


BAITCASTING REEL TATULA CT 100H/100HS/100P/100XS



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	H93-0401	SET PLT SCREW	66		WORM SHAFT
2	E16-7101	SPRING	67	G72-0001	WORM SHAFT BEARING
3	H93-0233	BRAKE ADJ KNOB	68	H91-0501	WORM GEAR
4	B33-9801	BRAKE DIAL RET	69		RETAINER
5	F63-7701	BRAKE DIAL WASHER	70	G09-9800	WASHER
6	H66-3401	BRAKE CLICK SPRING	71	320-8002	RETAINER
7	H93-0103	L/S PLATE	72	B35-8607	BALL BEARING
8	H91-5501	BRAKE DIAL RET	73	H92-8901	
9	G93-9301	FRONT PLT SCREW	74	E13-4509	SCREW
10	H93-0501	MAGNET HOLDER	75	H91-2701	DRIVE SHAFT GEAR
11	375-7400	SPACER A	76	H91-1601	DRIVE SHAFT
12	375-7411	SPACER B	77	H92-9401	A/R RATCHET
13	G18-5101	SPACER C	78	J08-5101	DRIVE SHAFT WASHER
14	G51-1503	BALL BEARING	79	H91-3102	DRIVE GEAR
15	F03-2201	BEARING RET	80	H45-2602	DRAG WASHER
16-24	Z02-2784	SPOOL ASSEMBLY	81	H91-3201	KEY WASHER
25	J33-7901	FRAME	82	J37-7801	GEAR SHAFT COLLAR
26	J24-4002	FRONT PLT	83	G81-9801	ROLLER CLUTCH
27	H84-2803	SCREW	84	B86-1704	BALL BEARING
28	J33-5001	CLUTCH LEVER	85	B55-3801	WASHER
29	H91-5601	CLUTCH LEVER PLT	86	F02-8203	CLICK LEAF SPRING HOLDER
30	H91-5701	CLUTCH LEVER PLT	87	F03-2401	CLICK LEAF SPRING
31	J24-4101	STABILIZER BAR	88	150-8901	SPRING WAHSER
32	H70-4101	RETAINER	89	H92-9501	WASHER
33	H91-0601	COLLAR	90	H91-2001	NUT
34	H92-8801	SPRING B	91	J01-1901	SPRING
35	J05-5201	PIN	92	H91-1901	STAR DRAG
36	B86-1704	BALL BEARING	93	F57-6601	HANDLE COLLAR
37	J24-2801	PLATE A	94	J14-2801	HANDLE ASSEMBLY
38	H29-4101	SCREW	95		HANDLE NUT
39	J24-3201	CLUTCH CAM SPRING	96	H83-4512	HANDLE NUT PLT
40	J22-1401	CLUTCH TRIP LEVER	97	353-8301	HANDLE SCREW
41	J24-2601	CLUTCH CAM PLT			
42	H15-9201	WASHER			HS SPECIAL PARTS
43	352-2501	SCREW	Key No.	Part No.	Part Name
44	H65-9101	CLUTCH CAM PLT	3		BRAKE ADJ KNOB
45	B03-2904	SCREW	48		PINION GEAR
46	H92-9001	YOKE	51	J21-2108	•
47	H58-2001	YOKE SPRING	79		DRIVE GEAR
48	H91-3901	PINION GEAR	96	H83-4504	HANDLE NUT PLT
49	H18-0501	BEARING RET			
50	G43-1102	BALL BEARING			OP SPECIAL PARTS
51	J21-2107	R/S PLATE	Key No.	Part No.	Part Name
52	B05-5201	O' RING	3		BRAKE ADJ KNOB
53	J21-3101	SPACER F	48		PINION GEAR
54	B17-5503	SPACER	51	J21-2112	-
55	J28-8202	CAST CONTROL CAP	79		DRIVE GEAR
56	G04-0814	R&L/S PLT SCREW	96	H83-4507	HANDLE NUT PLT
57	G04-0801	SCREW			
58	320-5901	RETAINER	W		XS SPECIAL PARTS
59	B41-1700	WASHER	Key No.	Part No.	Part Name
60	G72-0001	WORM SHAFT BEARING	3		BRAKE ADJ KNOB
61	J24-3303	T-LEVEL WIND	48		PINION GEAR
62	121-4212	LINE GUIDE PAWL	51	J21-2113	•
63 64	373-1300	WASHER	79 96		DRIVE GEAR
	F40-2801	PAWL CAP	96	п83-4506	HANDLE NUT PLT
65	J24-3701	LEVEL WIND GUARD			