


# DAIWA BAITCASTING REEL

Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

# TAT150HSL



Key No	Part No	Description	Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW	54	B17-5503	MECHANICAL BRAKE WASHER (B)
2	E16-7101	BRAKE DIAL SPRING	55	J00-4707	MECHANICAL BRAKE KNOB
3	J21-3702	BRAKE DIAL	56	G04-0820	LS PLATE SCREW (A)
4	B33-9801	BRAKE DIAL RETAINER(A)	57	320-5901	WORM SHAFT RETAINER(A)
5	F63-7701	BRAKE DIAL WASHER	58	B41-1700	WORM SHAFT WASHER(0.1MM)
6	H66-3401	BRAKE DIAL LEAF SPRING	59	G72-0001	WORM SHAFT COLLAR
7	H94-4932	RS PLATE	60	J17-6601	LEVEL WIND
8	H91-5501	BRAKE DIAL RETAINER(B)	61	121-4212	PAWL
9	G93-9301	BRAKE DIAL RETAINER(B)SCREW	62	373-1300	PAWL WASHER(0.1MM)
10	H93-0502	MAGNET HOLDER	63	F40-2801	PAWL HOLDER NUT
11	375-7400	RS BALL BEARING WASHER(A)(0.1MM)	64	H94-4601	WORM SHIELD
12	375-7411	RS BALL BEARING WASHER(B)	65	G72-0001	WORM SHAFT
13	G18-5101	RS BALL BEARING WASHER(C)	66	H91-1701	WORM SHAFT COLLAR
14	G51-1503	RS BALL BEARING	67	H91-0501	WORM SHAFT GEAR
15	F03-2201	RS BALL BEARING RETAINER	68	B33-9801	WORM SHAFT RETAINER(B)
16-24	Z02-1272	SPOOL ASSEMBLY	69	G09-9800	GEAR SHAFT WASHER(0.1MM)
25	H94-3925	FRAME	70	320-8002	GEAR SHAFT RETAINER
26	J21-3603	FRONT COVER	71	B35-8605	GEAR SHAFT BALL BEARING
27	H45-5407	FRONT COVER SCREW	72	H92-8901	GEAR SHAFT PLATE
28	H91-2401	CLUTCH LEVER	73	E13-4509	GEAR SHAFT PLATE SCREW
29	H91-5701	CLUTCH LEVER PLATE (R)	74	H91-2701	WORM GEAR
30	H91-5601	CLUTCH LEVER PLATE (L)	75	H91-1602	GEAR SHAFT
31	H91-2101	OSCILLATING POST	76	H92-9401	RATCHET
32	H70-4101	OSCILLATING POST RETAINER	77	J08-5101	DRIVE GEAR WASHER
33	H91-0601	CLUTCH CAM PLATE PIN SPRING COLLAR	78	J07-6602	DRIVE GEAR
34	H92-8801	CLUTCH CAM PLATE PIN SPRING	79	H45-2602	DRAG WASHER
35	J05-5201	CLUTCH CAM PLATE PIN	80	H91-3201	DRAG DISC WASHER
36	B86-1704	CLUTCH CAM BALL BEARING	81	J37-7801	DRAG COLLAR
37	H94-4301	KICK LEVER PLATE(A)	82	G81-9801	ONEWAY CLUTCH
38	H29-4101	KICK LEVER PLATE (A) SCREW	83	B86-1704	CLUTCH CAM BALL BEARING
39	H47-3301	KICK LEVER SPRING	84	B55-3801	HANDLE BALL BEARING WASHER
40	J22-1501	KICK LEVER	85	F02-8203	DRAG HOLDER
41	H94-4001	CLUTCH CAM	86	F03-2401	DRAG HOLDER LEAF SPRING
42	H15-9201	CLUTCH CAM SCREW WASHER	87	150-8901	DRAG SPRING WASHER
43	352-2501	CLUTCH CAM SCREW	88	H92-9501	STAR DRAG WASHER
44	H65-9101	KICK LEVER PLATE (B)	89	H91-2002	DRAG NUT
45	B03-2904	KICK LEVER PLATE (B) SCREW	90	J01-1901	DRAG NUT SPRING
46	H94-4401	CLUTCH PLATE	91	H91-1901	STAR DRAG
47	J05-5301	CLUTCH SPRING	92	F57-6601	HANDLE WAHSER
48	J09-2101	PINION GEAR	93	J09-1201	HANDLE ASSEMBLY
49	E21-9701	PINON RETAINER	94	H72-3702	HANDLE NUT
50	G43-1102	PINION BALL BEARING	95	J21-3502	HANDLE LOCK PLATE
51	H94-3834	LS PLATE	96	G04-0803	HANDLE LOCK PLATE SC
52	171-5201	MECHANICAL BRAKE O-RING	97	G04-0829	LS PLATE SCREW (B)
53	B17-5406	MECHANICAL BRAKE WASHER (A)			