


FLY REEL 731A



KEY NO. 1 ~ 6
6-736-1401

SPOOL ASSEMBLY

KEY NO. 9 ~ 11
6-781-4201

STAND ASSEMBLY

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	353-0001	Cover screw	15	144-2901	Friction spring
2	130-4701	Cover	16	171-3501	Body ring
3	375-3801	Cover washer	17	320-7601	Click spring retainer
4	144-1801	Spool stopper spring	18	151-5402	Click spring
5	541-3401	Spool stopper	19	750-3301	Click gear
6	736-0501	Spool	20	320-5901	Click claw retainer
7	353-3501	Screw	21	030-5201	Click claw
8	560-5401	Ring	22	461-3201	Cam
9	610-3401	Stand	23	706-5901	Body
10	050-6011	Stand pillar	24	151-5301	Click lever washer
11	353-3601	Stand screw	25	541-3501	Click lever
12	171-1301	Click gear retainer	26	352-2501	Click lever screw
13	050-6101	Pillar	27	353-3501	Screw
14	310-1101	Line guard			