


# YAMAHA

## SPINNING REEL

# Exist LT2500-XH

\*Please order by parts number, not key number.



Key No	Part no	Description
1	J55-6801	DRAG KNOB
2	J55-6701	DRAG RING
3	J55-6601	DRAG RATCHET
4	J67-9101	ATD DRAG WASHER( 1pac-3pcs )
5	J56-1201	DRAG LIP WASHER
6	J65-6501	DRAG DISC WASHER
7	B35-8702	BEARING RETAINER
8	G21-2503	SPOOL BALL BEARING
9	J55-6001	SPOOL ASSY ( 2-12)
10	J55-8001	LINE STOPPER
11	J55-8101	LINE STOPPER PLATE
12	J31-4801	LINE STOPPER SPRING
13	J54-6300	SPOOL WASHER ( A )
14	J54-9501	SPOOL METAL
15	J55-8201	SPOOL METAL SCREW
16	G52-2705	SPOOL METAL BALL BEARING
17	J60-2201	SPOOL WASHER ( B )
18	M02-1401	CLICK HOLDER
19	H41-6101	CLICK LEAF SPRING
20	G47-1501	ROTOR NUT PLATE
21	J72-9101	ROTOR NUT PACKING
22	375-5202	ROTOR NUT BEARING WASHER
23	H95-9602	ROTOR NUT BALL BEARING
24	J69-0201	ROTOR NUT COLLAR
25	J25-3001	ROTOR NUT
26	J80-8501	ROTOR NUT BEARING COLLAR
27	371-2836	ROTOR NUT WASHER
28	H02-2701	ROTOR NUT SCREW
29	J53-8101	ROTOR COVER
30	H02-2701	ROTOR COVER SCREW
31	J53-6801	ROTOR
32	J43-5201	KICK LEVER SPRING
33	J33-9502	KICK LEVER WASHER
34	J53-6901	KICK LEVER ASSY
35	H41-7701	KICK LEVER SCREW
36	J25-4601	ARM LEVER SHAFT
37	J25-4701	ARM LEVER SHAFT HOLDER
38	J53-7101	ARM LEVER SPRING COVER
39	J25-5201	COVER SCREW
40	J25-4801	ARM LEVER
41	J25-4901	ARM LEVER SCREW COLLAR
42	J25-5001	ARM LEVER SCREW
43	J25-7001	ROLLER SCREW
44	J53-8001	ROLLER COLLAR
45	J53-8401	ROLLER MAG COLLAR( A )
46	J25-6702	ROLLER BALL BEARING
47	J25-6601	ROLLER COLLAR ( A )
48	J25-6301	ROLLER COLLAR ( B )
49	J25-6502	LINE ROLLER
50	J25-6401	ROLLER COLLAR ( C )
51	J53-7801	ROLLER MAG COLLAR( B )
52	J89-0701	BAIL ASSY
53	J25-4901	BAIL HOLDER SCREW COLLAR
54	J25-5001	BAIL HOLDER SCREW
55	G47-1803	BAIL SPRING SHAFT
56	G68-5401	BAIL SPRING SHAFT WASHER
57	G68-5301	BAIL SPRING
58	G47-1601	BAIL SPRING SHAFT HOLDER

Key No	Part no	Description
59	J53-7701	BAIL HOLDER COVER
60	J25-5201	COVER SCREW
61	J55-4901	ROTOR PACKING
62	J55-4501	STOPPER CAP ASSY
63	J55-4701	STOPPER CAP SCREW
64	J55-3803	MAGSEALED PLATE
65	H84-2805	MAGSEALED PLATE SCREW
66	H50-2203	MAGSEALED PLATE WASHER
67	H41-2602	ONEWAY CLUTCH
68	J55-3701	STOPPER CAP PACKING
69	J55-4801	CLUTCH RING
70	J53-6202	CLUTCH RING COLLAR
71	J55-2101	PINION BEARING PLATE
72	J55-2201	PLATE SCREW
73	G27-9602	PINION BALL BEARING ( A )
74	375-8502	PINION BEARING WASHER ( A )
75	202-3645	PINION + DRIVE GEAR SET
76	H81-4902	PINION SPRING WASHER
77	E09-6501	PINION BEARING WASHER ( B )
78	G53-8007	PINION BALL BEARING ( B )
79	J55-2001	PINION BEARING COLLAR
80	J55-0808	BODY ASSY
81	J55-1701	MAIN SHAFT
82	J55-3101	OSCILLATING POST
83	J55-3201	REAR CAP PACKING
84	J55-3301	REAR CAP
85	J60-9102	BAIL KICK COLLAR SCREW
86	J71-8501	BAIL KICK COLLAR WASHER
87	J71-8601	BAIL KICK COLLAR O-RING
88	J55-3501	BAIL KICK COLLAR
89	J55-3601	REAR CAP SCREW
90	G31-5301	REAR CAP SCREW WASHER(A)
93	J55-4101	DRIVE BEARING ( B ) O-RING
94	J04-6802	DRIVE BALL BEARING ( B )
95	J55-1201	SET PLATE
96	J55-1301	SET PLATE O-RING
97	J55-5501	COVER WASHER
98	J55-2802	SIDE COVER ( R )
99	G39-9702	HANDLE CAP O-RING
100	J55-5901	HANDLE CAP
101	J55-1401	OSCILLATING GEAR WASHER
102	J55-1501	OSCILLATING GEAR
103	G68-3301	OSCILLATING GEAR O-RING
104	H12-9201	OSCILLATING GEAR WASHER
105	G68-6904	OSCILLATING GEAR BALL BEARING
106	G94-0401	OSCILLATING GEAR SCREW
107	J73-1701	DRIVE GEAR O-RING
108	J55-2701	DRIVE GEAR RING
109	J03-0303	DRIVE BALL BEARING ( A )
110	G61-3403	DRIVE BEARING WASHER
111	J55-6301	BODY COVER O-RING ( A )
112	J55-3001	BODY COVER O-RING ( B )
113	J55-2907	BODY COVER ( L )
114	J55-5103	HANDLE ASSY
115	G71-2401	OSCILLATING POST WASHER
116	G68-3301	OSCILLATING POST O-RING
117	G31-5301	REAR CAP SCREW WASHER ( B )