


# JUPITER-Z2500T



Key No.	Parts No.	Parts Name
2-9	F61-0101	SPOOL
1	F32-2105	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	E46-7201	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	E46-7101	SPOOL WASHER
11	270-6501	CLICK GEAR
12	F61-9401	MAIN SHAFT
13	F39-5801	OSC SLIDER
14	351-0315	OSC SLIDER SCREW
15	341-9201	ROTOR NUT
16	F31-1403	ROTOR
17	B67-9304	LINE ROLLER SCREW
18	F61-9201	BAIL ARM
19	B84-2102	BAIL ARM SCREW
20	F44-6302	LINE ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F47-3401	LINE ROLLER BUSHING
23	F45-4901	LINE ROLLER
24	F61-9601	BAIL
25	E45-1601	BAIL TRIP LEVER

Key No.	Parts No.	Parts Name
26	F12-8901	BAIL SPRING
27	F31-0311	BAIL SPRING COVER
28	E38-4202	BAIL SPRING COVER SCREW
29	F31-0404	BAIL TRIP COVER
30	E38-5501	SPRING HOLDER
31	F31-1502	A/R RATCHET
32	L03-6601	BALL BEARING
33	L01-3902	PINION GEAR
34	F60-9801	BODY
35	L00-1801	A/R PAWL SCREW
36	L01-4401	A/R PAWL
37	L01-4302	A/R PAWL COLLAR
38	L00-1501	A/R PAWL SPRING
39	E03-7801	BEARING RET SCREW
40	F38-5901	A/R CAM SPRING
41	F08-5121	A/R LEVER
42	F60-6001	OSC GEAR
43	F08-4801	DRIVE GEAR
44	373-7808	DRIVE GEAR WASHER
45	F60-9901	SIDE COVER
46	B83-5002	SIDE COVER SCREW
47	B92-4902	HANDLE LOCK WASHER
48	F03-5605	HANDLE LOCK SCREW
49	F61-2301	HANDLE