


SPINNING REEL LAGUNA 3550



Key No.	Parts No.	Parts Name
1	6W3800030	Spool Assembly
1	6W3800040	Spool Assembly (Extra Spool)
2	6W3402010	Bail Holder Nut
3	6W3881010	Counter Weight
4	6W3802010	Screw (A)
5	6W3803020	Main Shaft
6	6W3379030	Bail Assembly
7	6W3380020	Ball Bearing (A)
8	6W3806020	Line Roller
9	6W3382010	Collar (A)
10	6W3386010	Bail Arm
11	6W3809020	Screw (B)
12	6W3384010	Screw (C)
13	6W3811020	Rotor Nut
14	6W3391010	Screw (D)
15	6W3395010	Rotor Nut Holding Plate
16	6W3814010	Main Shaft Spring (A)
17	6W3398010	Collar (B)
18	6W3816020	Ball Bearing (B)
19	6W3400010	Spacing Sleeve (A)
20	6W3397010	Main Shaft Spring (B)
21	6W3819010	Screw (E)
22	6W3403030	Cover (A)
23	6W3387020	Bail Spring Shaft
24	6W3822020	Bail Spring
25	6W3389010	Bail Spring Holder
26	6W3401030	Rotor
27	6W3405010	Bail Trip Lever Spring
28	6W3406020	Bail Trip Lever
29	6W3407030	Screw (F)
30	6W3829010	Screw (G)
31	6W3409010	Bearing Retainer (A)
32	6W3417010	Ball Bearing (C)
33	6W3411010	Bearing Retainer (B)
34	6W3412010	Collar (C)
35	6W3415010	Washer (A)
36	6W3414010	Roller Clutch
37	6W3416010	Collar (D)
38	6W3837050	Pinion Gear
39	6W3838010	Screw (H)
40	6W3445010	Anti-Reverse Pawl
41	6W3444010	Anti-Reverse Pawl Spring
42	6W3420030	Anti-Reverse Cam
43	6W3842010	Screw (I)
44	6W3843050	Body
45	6W3448020	Handle Screw
46	6W3447020	Collar (E)
47	6W3436010	Ball Bearing (D)
48	6W3436010	Ball Bearing (D)
49	6W3439010	Anti-Reverse Cam Spring (A)
50	6W3438020	Drive Gear
51	6W3437010	Washer (B)
52	6W3850010	Retainer (A)
53	6W3851010	Click Leaf Spring (A)
54	6W3852050	Side Cover
55	6W3853010	Screw (J)
56	6W3854050	Handle Assembly
57	6W3855010	Screw (K)
58	6W3856020	Oscillating Slider Retainer
59	6W3857020	Oscillating Slider
60	6W3427030	Oscillating Gear
61	6W3850010	Retainer (B)
62	6W3859010	Click Leaf Spring (B)
63	6W3424010	AntiReverse Lever
64	6W3861010	Screw (L)
65	6W3862010	Washer (C)
66	6W3863020	Drag Metal (A)
67	6W3864010	Drag Washer (A)
68	6W3865010	Eared Washer
69	6W3866010	Drag Washer (B)
70	6W3867010	Key Washer
71	6W3868010	Drag Coil Spring
72	6W3869010	Washer (D)
73	6W3870010	Drag Screw
74	6W3871010	Drag Metal (B)
75	6W3872010	Collar (F)
76	6W3873010	Drag Cover
77	6W3874050	Rear Cover (A)
78	6W3875020	Rear Cover (B)
79	6W3876010	Screw (M)
80	6W3877010	"O" Ring
81	6W3878010	Drag Knob
82	6W3879010	Screw (N)
83	6W3880010	Cap