


**SPINNING REEL SWEEPFIRE3500A/4000A**



Key No.	Parts No.	Parts Name
1	W51-7601	DRAG KNOB ASSY
2	W33-5901	DRAG WASHER RET
3	W33-6002	KEY WASHER
4	W33-6102	EARED WASHER
5	W33-6202	DRAG WASHER
7	W30-1901	CLICK PAWL
8	W30-2101	CLICK SPRING
9	W38-6101	A/R LEVER SCREW
2-9	W51-7701	SPOOL
10	W33-9001	BAIL ARM SCREW
11	W33-7912	BAIL
12	W34-5202	LINE ROLLER BUSHING
13	W33-8404	LINE ROLLER
14	W30-6101	LINE ROLLER WASHER A
15	W33-8202	LINE ROLLER COLLAR
16	W33-8301	LINE ROLLER SCREW
17	W33-8401	BAIL ARM SCREW
18	W51-5702	BAIL ARM
19	W33-8702	BAIL SPRING SHAFT
20	W33-8802	BAIL SPRING
21	W33-8901	BAIL SPRING HOLDER
22	W33-9206	MAIN SHAFT
23	W45-3601	MAIN SHAFT WASHER
24	W33-9402	CLICK GEAR
25	W33-9101	ROTOR NUT HOLD PLT SCREW
26	W33-9501	ROTOR NUT HOLD PLT
27	W33-9601	ROTOR NUT
28	W51-5802	ROTOR
29	W34-0201	BAIL HOLDER NUT
30	W51-7801	BAIL SPRING COVER
31	W34-0401	BAIL SPRING COVER SCREW
32	W34-0501	BAIL TRIP LEVER SPRING
33	W34-0602	BAIL TRIP LEVER
34	W45-3801	BAIL TRIP LEVER WASHER
35	W34-0703	BAIL TRIP LEVER SCREW
36	W34-0701	BEARING RET A SCREW

Key No.	Parts No.	Parts Name
37	W44-0001	BEARING RET A
38	W45-4001	BALL BEARING
39	W34-1101	BEARING RET
40	W42-4001	SPACING SLEEVE
41	W47-0601	PINION GEAR
42	W50-7501	A/R CAM SPRING A
43	W34-2003	A/R CAM
44	W34-4301	A/R PAWL SCREW
45	W34-4202	A/R PAWL
46	W50-4401	A/R PAWL SPRING
47	W34-4101	A/R PAWL COLLAR
48	W34-2102	REAR COVER A SCREW
49	W51-8902	BODY
50	W48-7301	HANDLE LOCK SCREW
51	W34-4702	HANDLE COLLAR
52	W34-2501	A/R LEVER SCREW
53	W46-7901	A/R LEVER
54	W45-4601	REAR COVER B
55	W51-6102	REAR COVER A
56	W44-1001	OSC GEAR COLLAR
57	W34-2703	OSC GEAR
58	W34-2803	OSC SLIDER
59	W34-2901	OSC SLIDER SCREW
60	W34-4001	A/R CAM SPRING B
61	W34-3902	A/R PAWL SPRING A
62	W51-7901	DRIVE GEAR BUSHING
63	W34-3802	DRIVE GEAR
64	W34-3701	DRIVE GEAR WASHER
65	W51-6202	SIDE COVER
66	W34-3201	SIDE COVER SCREW A
67	W34-3101	SIDE COVER SCREW B

**SW4000A Special parts**

Key No.	Parts No.	Parts Name
2-9	W51-8101	SPOOL